



AD-A276 629



PART 2 OF 2

Office of Naval Research  
Grant N00014-89-J-1795

Final Report

DTIC  
ELECTE  
MAR 09 1994

S

E

D

# Noninvasive Spectral Analysis and Beam Mapping of Focused Ultrasound

by

Walter Mayer (Principal Investigator)

Thomas Neighbors

Herbert Ruf

John Wolf

Qicao Zhu

Ultrasonics Research Laboratory


Physics Department

Georgetown University

Washington, DC 20057

January 1994

Reproduction in whole or in parts permitted for any purpose  
of the United States Government



94-05139



94 2 16 008

Summary Page IV

Appendices

This appendix section contains the various codes that were used to do the numerical analysis discussed in Section I.

Also included here are two papers which were prepared to conclude the work carried out during an earlier period of the Grant, preceding the work on focused beams. This work was to be in preparation for an anticipated later effort to merge the focused beam work and the earlier work on plate excitation by bounded, but non-focused beams. Unfortunately, the results presented here could not be used in conjunction with the results presented in Section I due to the decision not to continue the Grant.

Accession For	
NTIS	CRA&I <input checked="checked" type="checkbox"/>
DTIC	TAB <input type="checkbox"/>
Unannounced <input type="checkbox"/>	
Justification <i>Per A276211</i>	
By .....	
Distribution /	
Availability Codes	
Dist	Avail and/or Special
<i>A-1</i>	

APPENDIX A  
LFOCUS.EXE  
USER'S GUIDE

## A.1. INTRODUCTION

This appendix outlines the steps necessary for using the line focus software, **LFOCUS.EXE**, developed to support ONR research on optical probing of ultrasonic fields. Section A.2 outlines the hardware requirements for program execution. Since the software is menu driven rather than batch processed, Section A.3 provides a short user's guide for the menu driven interface. Section A.4 describes the output file structure used for data post processing.

## A.2. Hardware Requirements

The minimum hardware configuration required to operate **LFOCUS.EXE** consists of a computer with an Intel 80386 Central Processing Unit (CPU) or 80486 CPU with the following features:

- one high density, 3½" or 5¼" floppy disk drive,
- PC Disk Operating System (DOS) Version 3.3 or later<sup>1</sup>,
- Monochrome display or display adapter,
- Intel 80387 Math CO-Processor<sup>2</sup>,
- A hard drive with 40 to 50 Mega-Bytes (Mb) of available storage, and

---

<sup>1</sup> Program compatibility has been verified with MS-DOS v 3.3 and 4.01 and Digital Research DOS v 5.0 and 6.0.

<sup>2</sup> The 80486 chip has an integral co-processor.

- 4.0 Mb of extended memory.

**LFOCUS.EXE** accesses the Intel co-processor and will not run without it. As an alternative, the program can be compiled to access the Weitek, ABACUS chip. This change could improve program execution speed by about a factor of two. A graphics monitor does not improve program performance. Additional hard disk storage space is only useful for multiple program runs. A Microsoft® or compatible mouse can be used as a pointing device for program execution; however, a mouse is not required for program execution.

### A.3. Initial Execution

To run **LFOCUS.EXE** for the first time change to the hard disk directory which contains the program, type **LFOCUS**, and press <Enter>. **LFOCUS.EXE** loads and presents the initial menu screen shown in Figure A.1.





Figure A.1. LFOCUS.EXE Initial Menu

If a mouse is present, move the mouse cursor over the desired function and click the left mouse button to execute the function. If a mouse is not present, press the highlighted key to execute the function. For example, the initial menu can be activated by pressing the **Alt** key and **W** to select the Data Entry Window, moving the mouse cursor over Data Entry Window and clicking the left mouse button, or pressing **F10**. If the Data Entry Window function is executed by either technique, the first pull-down menu appears as shown in Figure A.2.



**Figure A.2. Data Entry Options**

**Run Parameters (F6)** specifies the number of spectra used in the calculations (minimum and maximum) and the on and off-axis data output points. **Off-Axis Data Points (F7)** specifies the on-axis locations where the off-axis data points are output to a disk file. **Transducer (F8)** specifies the key parameters associated with the line focus transducer, such as, dimensions, aperture angle, initial on-axis pressure, etc.. **Boundary Values (F9)** provides options for specifying the pressure amplitude distribution at the transducer surface. To activate a menu press the highlighted key, the specified function key, or use the mouse cursor and click on the choice.

### A.3.1. Run Parameters

To specify the input parameters for a run press **R**, function key **F6**, or highlight the **Run Parameters** option with the mouse cursor and click. The **Run Parameters** menu shown in Figure A.3 appears. The parameter values displayed are those used the last time the program was executed. To exit this menu without changing any values, use the mouse cursor to click the **[■]** symbol or press **<Enter>**. To move through the parameters on the menu without a mouse, press the **Tab** key. Each time the **Tab** key is pressed the next menu option is highlighted for data entry. To back-up, press **Shift Tab** and the previous data entry option is highlighted for data entry. To select a field for data entry move the mouse cursor over the text describing the value and click.

Data Entry Window

☐

Run Parameters

Use Tab Key or Mouse to select data entry field

Minimum # Spectra	(4 to 49):	5
Maximum # Spectra	(Min # to 50):	26
Number On-Axis Points	(100 to 400):	300
Number Off-Axis Points	(1 to 40):	30
Radial Step Size	(0.02 to 0.001):	0.005
Min On-Axis Output	(0.001 to 0.99):	0.001
Max On-Axis Output	(1.05 to 2.0):	1.4
Max Off-Axis Range	(1.1 to 10.0):	10
Max Off-Axis Points	(10 to 200):	200

Error Message

Ok

Cancel

F10 Opens Menu <Esc> Closes Menu Alt-X Exits Program

Figure A.3. Run Parameters Menu

To enter in a new value key in the appropriate number. Do not press **Enter**, if you wish to change other values before exiting the menu. Pressing **<Enter>** will exit the menu, if there are no errors. If a value is keyed in which is out of range, an error message appears when you attempt to exit the menu. For example, **Minimum # Spectra** represents the number of spectral terms present at the start of a calculation. As shown, this is allowed to

take on a value between 4 and 49 terms. If a value outside of this range is keyed in, such as 2, the program writes the error message shown in Figure A.4 when the <Enter> key is pressed. The program will not exit the menu until the entry is corrected. If multiple errors are made when keying in values, each error has to be corrected.




Figure A.4. Typical Error Message

The data entry values covered in the Run Parameters menu include:

Minimum # Spectra	minimum number of spectral terms present at the start of a calculation,
Maximum # Spectra	maximum number of spectral terms allowed in the calculation, that is the number of terms allowed before the Fourier spectra is truncated,
Number On-Axis Points	number of on-axis points where the amplitude and phase spectra are saved during the calculation,
Number Off-Axis Points	number of points on the axis where the off-axis amplitude and phase spectra are saved during the calculation,
Radial Step Size	normalized, transverse mesh step size used in the calculation,



<b>Min On-Axis Output</b>	the on-axis point where the on-axis output starts (0 is at the face of the transducer and 1 is at the geometric focal point),
<b>Max On-Axis Output</b>	the on-axis point where the calculation is terminated and the last on-axis data values are written to a file,
<b>Max Off-Axis Range</b>	maximum normalized size the transverse grid is allowed to expand to during the calculations, and
<b>Max Off-Axis Points</b>	maximum number of off-axis points which are output at each specified output location.

The values shown in Figures A.3 and A.4 within the brackets are the allowable data entry ranges.

### A.3.2. Off-Axis Data Point Menus

To review or change the on-axis locations selected for off-axis data output prior to running LFOCUS.EXE, select the data entry window and press O, F7, or use the mouse cursor to select **Off-Axis Data Points** from the options shown in Figure A.2. At this point, the **Off Axis Location 1** menu shown in Figure A.5 appears. Use the **Tab** or **Shift Tab** keys to move between the data entry fields. To exit without changing any values use the mouse to click on the **[■]** symbol or the **Ok** or **Cancel** buttons. Alternatively, use the **Tab** or **Shift Tab** keys to move to the **Ok** or **Cancel** buttons. The range of allowable off-axis data values is determined by the **Run Parameters** menu. For example, in menu shown in Figure A.3, the maximum on-axis output point is 1.4 (40% beyond the geometric focal point for the transducer). Data entry follows the technique previously described for the **Run Parameters** menu. Remember, the software will not exit a menu which has a value out of range. Also, the program expects the values to be *monotonically increasing*. This menu will continue to appear until all points have been selected for off-axis data output. Once the last data point has been selected, the program returns to the initial data entry menu shown in Figure A.1.




Figure A.5. Off-Axis Data Point Selection

### A.3.3. Transducer Characteristics Menu Data Entry

To review or change the transducer data values prior to running LFOCUS.EXE select the data entry window and press T, F8, or use the mouse cursor to select **Transducer** from the options shown in Figure A.2. At this point the **Transducer Characteristics** menu shown in Figure A.6 appears. Use the **Tab** or **Shift Tab** keys to move between the data entry fields. To exit without changing any values use the mouse to click on the [■] symbol or the **Ok** or **Cancel** buttons. Alternatively use the **Tab** or **Shift Tab** keys to move to the **Ok** or **Cancel** buttons. Data entry follows the technique previously described for the **Run Parameters** menu. Remember, the software will not allow the user to exit a menu which has a value out of range. Once the last data entry has been made the program returns to the initial data entry menu shown in Figure A.1.




Figure A.6. Transducer Data Entry

#### A.3.4. Boundary Value Menus

A three level menu system is used for selecting an existing or entering a new normalized pressure distribution across the face of the line focus transducer. To select this option from the choices presented in Figure A.2, press **B. F9**, or highlight **Boundary Value** with the mouse cursor and click. The **Transducer Pressure Distribution Options Menu** shown in Figure A.7 appears. This menu provides three choices for the pressure distribution at the transducer surface.

- Previous:** The distribution used in the previous run
- Uniform:** A uniform distribution, e.g. the peak pressure at each location on the surface of the transducer is assumed to be the same
- New:** The pressure distribution will be entered from the key board or a data file




Figure A.7. Transduce Pressure Distribution Options

To select a value, either press the highlighted letter or move the mouse cursor over the option and click. The default is to use the normalized pressure distribution for the previous run. To change to uniform distribution, press **U** or move the mouse cursor over **Uniform** and click. To enter a new pressure distribution, press **N** or use the mouse cursor to click on **New**. If **New** is selected, the source choices become active. The default is to read an existing data file which describes the pressure distribution. To enter a new data file, press **E** or click on **Enter Data** with the mouse cursor. Once the final choice has been made, press **<Enter>**, **O**, or click on **Ok** with the mouse cursor.

If the source option is **Use File**, the **Pressure Distribution File Name Menu** shown in Figure A.8 appears. Press **F**, use the **Tab** key, or the mouse cursor to select **File Name**. Key in the file name and press **<Enter>**. If an error occurs during the data entry, a descriptive message will appear in the **Error Message** window.




Figure A.8. Entering New File Name

Once the desired field name has been selected press <Enter>. To terminate the process at any time, tab to the **Cancel** button or click on this button with the mouse cursor.

A similar process is followed in generating a new data file. Select the **Enter Data** option from the menu shown in Figure A.7 and press <Enter>. The **New Pressure Distribution File Menu** shown in Figure A.9 appears. Press **F**, use the **Tab** key, or the mouse cursor to select **File Name**. Key in the file name. Use the **Tab** key or the mouse cursor to select **Number of points**. Key in a value between 1 and 100 and press <Enter>. If an error occurs during data entry, a descriptive message appears in the **Error Message** window. Use the **Tab** key or the mouse cursor to move to the data entry window that contains the error and key in a corrected value. To exit at any time without entering a new data file, use the **Tab** key or the mouse cursor to select the **Cancel** button and press enter or click on the button.




Figure A.9. Entering a new file name and number of points




Figure A.10. Entering New Pressure Distribution File

To enter the transducer amplitude distribution use the menu shown in Figure A.10. First use the Tab key or the mouse to select **Radial Point (m)**. The radial location is measured normal to the transducer axis of symmetry. The first entry must be the value on the symmetry axis, e.g. 0. After keying in the appropriate value use the Tab key or the

mouse to select **Normalized Pressure**. Key in a value between 0 and 1. If the radial location extends beyond the transducer boundary, an error message appears. Also, a normalized pressure greater than unity generates an error message. After the location and pressure value have been correctly entered, press <Enter> or the **Ok** button. After the last data entry is made, the program returns to the program main menu shown in Figure A.1.

### A.3.5. Program Execution

After data entry is completed, press **Alt-X** or use the mouse cursor to click the **Alt-X Exits Program** section of the menu shown in Figure A.1 to start program execution. Depending on the data values used and computer CPU speed, program execution can run from several hours to as much as a couple of days. While the program is executing, the status message shown below is written to the screen.

```
Nstep = 264 z = 0.136237 k = 29 m = 4 lmax = 113
Nstep = 273 z = 0.140900 k = 30 m = 4 lmax = 115
Nstep = 282 z = 0.145563 k = 31 m = 4 lmax = 115
```

Nstep is the calculation step number. Z is the normalized on-axis distance from the face of the transducer. K is the number of the output point. The current number of harmonic terms being used in the calculation is specified by m. Finally, lmax is the current location of floating outer boundary for the edge of the calculational mesh.

To interrupt program execution press **Ctrl-C** or **Ctrl-Break**. After two screen writing cycles, all relevant data is saved to the hard disk and normal program termination occurs. To restart the program, type **LFOCUS** and press <Enter>. When the program has finished running, it writes **PROGRAM EXECUTION COMPLETED** to the screen.

### A.4. Output Data File Structures

After **LFOCUS.EXE** has completed execution four text data files are written - amplitude and phase files for on-axis and off-axis data points. Figure A.11 summarizes the

relevant characteristics of AMPZ and PHASEZ - the on-axis amplitude and phase spectra output files. The first 44 lines in each file summarizes the input data used to conduct the run. This is followed in each case by the amplitude spectra or phase spectra, depending upon the file type. Since the number of spectral terms will vary, depending upon the nonlinearity of problem, e.g. initial pressure, effective focusing gain, etc., the first output is the number of spectral terms, the second output is the location along the z axis. The subsequent output terms are either the amplitude or phase spectra depending upon the file type. The amplitude spectral terms are normalized to the peak pressure. The phase terms are in radians.

```

                                Ampz. Data Structure
Lines 1 through 44 = file header
Line 45 through end = amplitude spectra with
  #      Z      A[0]      A[1]      A[2]      ...
  4      5.6633E-0003  0.0000E+0000  1.0032E+0000  6.2014E-0005  ...
  4      1.0327E-0002  0.0000E+0000  1.0057E+0000  1.0892E-0004  ...
  4      1.4990E-0002  0.0000E+0000  1.0081E+0000  1.5616E-0004  ...

                                Phasez. Data Structure
Lines 1 through 44 = file header
Line 45 through end = phase spectra with
  #      Z      Phi[0]      Phi[1]      Phi[2]      ...
  4      5.6633E-0003  0.0000E+0000  -4.8870E-0006  -6.4645E-0006  ...
  4      1.0327E-0002  0.0000E+0000  -1.4608E-0005  -1.8326E-0005  ...
  4      1.4990E-0002  0.0000E+0000  -2.9689E-0005  -3.6417E-0005  ...

```

Figure A.11. Ampz and Phasez Output Data Structure

A similar file structure is used for the off-axis points, as shown in Figure A.12. Again, the first 44 lines of AMPZR or PHASEZR summarize the input data. Line nine is an integer entry which specifies the number of off-axis data output points. Starting with the first output location, a record is written which contains the number of spectral terms used at the location, the normalized on-axis location, the normalized off axis location, and the first through  $n^{\text{th}}$  amplitude or phase terms.



Ampzr. Data Structure

Lines 1 through 44 = file header  
 Line 9 = number of-axis data output locations  
 Line 45 through end = amplitude spectra with

	Z	r[1]	A[0]	A[1]	...
5	7.5000E-0001	0.0000E+0000	0.0000E+0000	2.8336E+0000	...
		r[2]			
5	7.5000E-0001	2.0000E-0002	0.0000E+0000	2.7830E+0000	...
		r[3]			
5	7.5000E-0001	4.0000E-0002	0.0000E+0000	2.8362E+0000	...

Phasezr. Data Structure

Lines 1 through 44 = file header  
 Line 9 = number of-axis data output locations  
 Line 45 through end = amplitude spectra with

	Z	r[1]	Phi[0]	Phi[1]	...
5	7.5000E-0001	0.0000E+0000	0.0000E+0000	9.7667E+0000	...
		r[2]			
5	7.5000E-0001	2.0000E-0002	0.0000E+0000	1.0189E+0001	...
		r[3]			
5	7.5000E-0001	4.0000E-0002	0.0000E+0000	1.1529E+0001	...

Figure A.12. Ampzr and Phasezr Output Data Structure

The amplitude spectra are normalized relative to the initial input pressure and the phase spectral terms are in degrees.

APPENDIX B

MENU.PAS

PROGRAM LISTING

This appendix provides a listing of the menu program used by LFOCUS.EXE. This program is written in Turbo Pascal v 6.0 and called by the FORTRAN code during initial execution. Since the program uses the standard Turbo Vision applications framework, only the unique source code is commented.

```

program MENU;

uses Objects,
    Drivers,
    Views,
    Menus,
    Dialogs,
    App;

const
    MaxLines      = 100;
    WinCount: Integer = 0;
    cmFileOpen    = 100;
    cmNewWin      = 101;
    cmNewDialog   = 102;
    cmOffAxisData = 103;
    cmNewTransducer = 104;
    cmRunInput    = 105;
    cmBoundary    = 106;
    cmPrevious    = 107;
    cmUniform     = 108;
    cmNewFile     = 109;
    cmNewFileValues = 110;

var
    LineCount,
    MaxNumber,
    OffAxisIndex,
    code,
    n          : INTEGER;
    Lines: array[0..MaxLines - 1] of PString;
    errorflag  : BOOLEAN;

type
    (      Record types used by the program for temporary data I/O      )

    RunInputValues = record
        MINM      : STRING[128];
        MAXM      : STRING[128];
        Npoints   : STRING[128];
        NDpoints  : STRING[128];
        DeltaR    : STRING[128];
        Zmin      : STRING[128];
        Zmax      : STRING[128];
        Rgmax     : STRING[128];
        RadiusMax : STRING[128];
        errorMessage : STRING[128];
    end;

    TransducerData = RECORD
        Diameter : STRING[128];
        RadiusOfC : STRING[128];
        Frequency : STRING[128];
        Pressure  : STRING[128];
        errorMessage : STRING[128];
    end;

    ZuData = RECORD
        location : STRING[128];
        errorMessage : STRING[128];
    end;

    BoundaryData = RECORD
        RadioButtonDataA : Word;
        RadioButtonDataB : Word;
    end;

    FileNameData = RECORD
        Name : STRING[128];
        ErrorMessage : STRING[128];
    end;

```

```

FileNameData2 = RECORD
  Name      : STRING[128];
  NumberPoints : STRING[128];
  ErrorMessage : STRING[128];
end;

BoundaryDataValues = RECORD
  location      : STRING[128];
  NormalizedP   : STRING[128];
  ErrorMessage  : STRING[128];
end;

TMyApp = object(TApplication)
  procedure HandleEvent(var Event: TEvent); virtual;
  procedure InitMenuBar; virtual;
  procedure InitStatusLine; virtual;
  procedure NewTransducer;
  procedure RunParameters;
  procedure OffAxisData;
  procedure NewWindow;
  procedure SelectBoundary;
  procedure EnterFileName;
  procedure EnterFileName2;
  procedure BoundaryAxisData;
end;

PInterior = ^TInterior;
TInterior = object(TScroller)
  constructor Init(var Bounds: TRect; AHScrollBar, AVScrollBar: PScrollBar);
  procedure Draw; virtual;
end;

PDemoWindow = ^TDemoWindow;
TDemoWindow = object(TWindow)
  RInterior, LInterior: PInterior;
  constructor Init(Bounds: TRect; WinTitle: String; WindowNo: Word);
  function MakeInterior(Bounds: TRect; Left: Boolean): PInterior;
  procedure SizeLimits(var Min, Max: TPoint); virtual;
end;

PDemoDialog = ^TDemoDialog;
TDemoDialog = object(TDialog)
end;

var
  Transducer      : TransducerData;
  RunInput        : RunInputValues;
  Zu              : Array[0..50] of ZuDATA;
  BoundaryChoice  : BoundaryData;
  FileName        : FileNameData;
  FileName2       : FileNameData2;
  BoundaryChoiceValues : Array[0..100] of BoundaryDataValues;
  NumberBoundaryPoints : INTEGER;
  textfile        : TEXT;

constructor TInterior.Init(var Bounds: TRect; AHScrollBar, AVScrollBar: PScrollBar);
begin
  TScroller.Init(Bounds, AHScrollBar, AVScrollBar);
  Options := Options or ofFramed;
  SetLimit(128, LineCount);
end;

```

```

procedure TInterior.Draw;
var
  Color: Byte;
  I, Y: Integer;
  B: TDrawBuffer;
begin
  Color := GetColor(1);
  for Y := 0 to Size.Y - 1 do
    begin
      MoveChar(B, ' ', Color, Size.X);
      I := Delta.Y + Y;
      if (I < LineCount) and (Lines[I] <> nil) then
        MoveStr(B, Copy(Lines[I]^, Delta.X + 1, Size.X), Color);
      WriteLine(0, Y, Size.X, 1, B);
    end;
  end;

constructor TDemoWindow.Init(Bounds: TRect; WinTitle: String; WindowNo: Word);
var
  S: string[3];
  R: TRect;
begin
  Str(WindowNo, S);
  TWindow.Init(Bounds, WinTitle + ' ' + S, wnNoNumber);
  GetExtent(Bounds);
  R.Assign(Bounds.A.X, Bounds.A.Y, Bounds.B.X div 2 + 1, Bounds.B.Y);
  LInterior := MakeInterior(R, True);
  LInterior.GrowMode := gfGrowHiY;
  Insert(LInterior);
  R.Assign(Bounds.B.X div 2, Bounds.A.Y, Bounds.B.X, Bounds.B.Y);
  RInterior := MakeInterior(R, False);
  RInterior.GrowMode := gfGrowHiX + gfGrowHiY;
  Insert(RInterior);
end;

function TDemoWindow.MakeInterior(Bounds: TRect; Left: Boolean): PInterior;
var
  HScrollBar, VScrollBar: PScrollBar;
  R: TRect;
begin
  R.Assign(Bounds.B.X-1, Bounds.A.Y+1, Bounds.B.X, Bounds.B.Y-1);
  VScrollBar := New(PScrollBar, Init(R));
  VScrollBar.Options := VScrollBar.Options or ofPostProcess;
  if Left then VScrollBar.GrowMode := gfGrowHiY;
  Insert(VScrollBar);
  R.Assign(Bounds.A.X+2, Bounds.B.Y-1, Bounds.B.X-2, Bounds.B.Y);
  HScrollBar := New(PScrollBar, Init(R));
  HScrollBar.Options := HScrollBar.Options or ofPostProcess;
  if Left then HScrollBar.GrowMode := gfGrowHiY + gfGrowLoY;
  Insert(HScrollBar);
  Bounds.Grow(-1, -1);
  MakeInterior := New(PInterior, Init(Bounds, HScrollBar, VScrollBar));
end;

procedure TDemoWindow.SizeLimits(var Min, Max: TPoint);
var R: TRect;
begin
  TWindow.SizeLimits(Min, Max);
  Min.X := LInterior.Size.X + 9;
end;

```

```

(      This is the event handler used to call the data entry procedures.
cmNewTransducer      =      call to NewTransducer
cmRunInput            =      call to RunParameters
cmOffAxisData         =      call to OffAxisData
cmNewWin              =      call to NewWindow
cmBoundary            =      call to SelectBoundary
)

```

```

procedure TMyApp.HandleEvent(var Event: TEvent);
begin
  TApplication.HandleEvent(Event);
  if Event.What = evCommand then
  begin
    case Event.Command of
      cmNewWin      : NewWindow;
      cmNewTransducer : NewTransducer;
      cmRunInput    : RunParameters;
      cmOffAxisData : begin
        VAL(RunInput.NumberPoints,MaxNumber,Code);
        For OffAxisIndex := 1 To MaxNumber Do OffAxisData;
      end;
      cmBoundary    : begin
        SelectBoundary;
        Case BoundaryChoice.RadioButtonDataA Of
          0 :;
          1 : begin
            {This section sets a uniform aperture distribution}

            NumberBoundaryPoints      := 1;
            BoundaryChoiceValues[0].location := '0';
            BoundaryChoiceValues[0].NormalizedP := '1.0';
            end;
          2 : Case BoundaryChoice.RadioButtonDataB Of
            0 : begin
              EnterFileName;
              IF skipflag = FALSE THEN
              begin
                Assign(textfile,FileName.name);
                RESET(textfile);
                READLN(textfile,NumberBoundaryPoints);
                FOR n := 0 TO NumberBoundaryPoints - 1 DO
                  begin
                    READLN(textfile,BoundaryChoiceValues[n].location);
                    READLN(textfile,BoundaryChoiceValues[n].NormalizedP);
                    BoundaryChoiceValues[n].errorMessage := '';
                  end;
                FOR n := NumberBoundaryPoints TO 100 DO
                  WITH BoundaryChoiceValues[n] DO
                    begin
                      location      := '';
                      NormalizedP   := '';
                      errorMessage := '';
                    end;
                CLOSE(textfile);
              end;
            end;
          1 : begin
              EnterFileName2;
              IF skipflag = FALSE THEN
              begin
                VAL(FileName2.NumberPoints,NumberBoundaryPoints,Code);
                For OffAxisIndex := 0 to NumberBoundaryPoints - 1 Do BoundaryAxisData;
              end;
            end;
          end;
        end;
      end;
    else
      Exit;
    end;
    ClearEvent(Event);
  end;
end;

```

```

(      This is the interface for the pull-down menu system. It connects the commands with the keystrokes that activate
each individual command. For example, R or F6 are linked to cmRunInput which is used to call the procedure
RunParameters.
)

```

```

procedure TMyApp.InitMenuBar;
var R: TRect;
begin
  GetExtent(R);
  R.B.Y := R.A.Y + 1;
  MenuBar := New(PMenuBar, Init(R, NewMenu(
    NewSubMenu('Data Entry Window', hcNoContext, NewMenu(
      NewItem('Run Parameters', 'F6', kbF6, cmRunInput, hcNoContext,
      NewItem('Off-Axis Data Points', 'F7', kbF7, cmOffAxisData, hcNoContext,
      NewItem('Transducer', 'F8', kbF8, cmNewTransducer, hcNoContext,
      NewItem('Boundary Values', 'F9', kbF9, cmBoundary, hcNoContext,
      nil)))))
    nil)));
  ));
end;

```

```

(      This procedure controls the status line at the bottom of the main menu. It links the keys that open and close the
main menu.
)

```

```

procedure TMyApp.InitStatusLine;
var R: TRect;
begin
  GetExtent(R);
  R.A.Y := R.B.Y - 1;
  StatusLine := New(PStatusLine, Init(R,
    NewStatusDef(0, $FFFF,
      NewStatusKey('F10 Opens Menu <Esc> Closes Menu', kbF10, cmMenu,
      NewStatusKey('Alt-X Exits Program', kbAltX, cmQuit,
      nil)),
    nil)
  ));
end;

```

```

(      This procedure is used to check real input values to determine whether they are valid. If the data entry is not a real
number, the error flag is set to FALSE, the error message is set to the string error1, and the procedure branches to
the exit. If the data type is correct, the procedure checks to see whether the data entry is between the upper
(UpperLimit) and lower (LowerLimit) limits. If it is not, the error flag is set to FALSE, the error message is set
to the string error2, and the procedure branches to the exit.
)

```

```

procedure CheckRealData(VAR NewValue, NewValue2 : STRING;
                        error1, error2 : STRING;
                        VAR errorflag : BOOLEAN;
                        LowerLimit, UpperLimit : SINGLE);

  LABEL localout;
  VAR realvalue : SINGLE;

  begin
    Val(NewValue, realvalue, code);
    NewValue2 := '';
    IF code <> 0 THEN
      begin
        NewValue2 := error1;
        Errorflag := FALSE;
        GOTO localout;
      end;
    IF (realvalue < lowerlimit) OR (realvalue > upperlimit) THEN
      begin
        Errorflag := FALSE;
        NewValue2 := error2;
        GOTO localout;
      end;
    localout ;;
  end;

```



```

{      This procedure is used to check integer input values to determine whether they are valid. If the data entry is not
      an integer, the error flag is set to FALSE, the error message is set to the string error1, and the procedure branches
      to the exit. If the data type is correct, the procedure checks to see whether the data entry is between the upper
      (UpperLimit) and lower (LowerLimit) limits. If it is not, the error flag is set to FALSE, the error message is set
      to the string error2, and the procedure branches to the exit.
}

```

```

procedure CheckIntegerData(VAR NewValue, NewValue2 : STRING;
                           error1, error2 :STRING;
                           VAR errorflag : BOOLEAN;
                           LowerLimit, UpperLimit : SINGLE);

  LABEL localout;
  VAR integervalue : INTEGER;

  begin
    Val(NewValue,integervalue,code);
    NewValue2 := '';
    IF code <> 0 THEN
      begin
        NewValue2 := error1;
        Errorflag := FALSE;
        GOTO localout;
      end;
    IF (integervalue < lowerlimit) OR (integervalue > upperlimit) THEN
      begin
        Errorflag := FALSE;
        NewValue2 := error2;
        GOTO localout;
      end;
    localout :
    end;
  end;

```

```

{      This procedure checks to make sure that the filename conforms to PC-DOS standards
}

```

```

procedure CheckFileName(VAR name,errormessage:STRING);

  LABEL localout;

  begin {CheckFileName}

    errorflag := TRUE;
    errormessage := '';

    IF length(name)>12 Then
      begin
        Errorflag := FALSE;
        Errormessage := 'Length > 12 Characters!';
        GOTO localout;
      end;

    IF ((POS('.',name) > 9) or (POS('.',name) = 0)) and (length(name) >= 9) THEN
      begin
        Errorflag := FALSE;
        Errormessage := 'Name > 8 Characters!';
        GOTO localout;
      end;

    IF (Length(name) - POS('.',name)) > 3 THEN
      begin
        Errorflag := FALSE;
        Errormessage := 'Extension > 8 Characters!';
        GOTO localout;
      end;

    localout ;;

  end; {CheckFileName}

```

```

(      This procedure reads the input parameters for the run.      )

procedure TMyApp.RunParameters;
var
  Thomas: PView;
  Dialog: PDemoDialog;
  R: TRect;
  C: Word;
  errormessage,
  tempstring : STRING;
  yfirst,
  xleft,
  xright,
  xleft2,
  xright2,
  xleft3,
  xright3 : BYTE;
  lowervalue : INTEGER;

procedure CheckRunParameters;

(      This is the local procedure that checks the run parameter data entries. It uses CheckIntegerData and
  CheckRealData with the appropriate values.      )

VAR
  newcode,
  minimumM,
  maximumM : INTEGER;
  UpperBound : SINGLE;

LABEL Done;

begin
(      First set the errorflag      )

  RunInput.errormessage := '';
  errorflag := TRUE;

(      Then check each of the record values starting with the minimum number of spectral terms, Minm. If an error occurs
  in any of the checks, the error flag is set to FALSE before exiting the procedure.      )

  CheckIntegerData(RunInput.Minm,RunInput.errormessage,
    'Minimum Spectral Term Not Integer!',
    'Minimum Spectral Term Out Of Range!',errorflag, 3, 48);
  IF errorflag = FALSE THEN GOTO Done;

  VAL(RunInput.Minm,MinimumM,code);

  CheckIntegerData(RunInput.Maxm,RunInput.errormessage,
    'Maximum Spectral Term Not Integer!',
    'Maximum Spectral Term Out Of Range!',errorflag, MinimumM, 51);
  IF errorflag = FALSE THEN GOTO Done;

  CheckIntegerData(RunInput.Npoints,RunInput.errormessage,
    'Number Of On-Axis Points Not An Integer!',
    'Number Of On-Axis Points Out Of Range!',errorflag, 99, 401);
  IF errorflag = FALSE THEN GOTO Done;

  CheckIntegerData(RunInput.NDpoints,RunInput.errormessage,
    'Number Of Off-Axis Points Not An Integer!',
    'Number Of Off-Axis Points Out Of Range!',errorflag, 0, 41);
  IF errorflag = FALSE THEN GOTO Done;

  CheckRealData(RunInput.DeltaR,RunInput.errormessage,
    'Radial Step Size Not A Number!',
    'Radial Step Size Out Of Range!',errorflag, 0.001, 0.0201);
  IF errorflag = FALSE THEN GOTO Done;

  CheckRealData(RunInput.Zmin,RunInput.errormessage,
    'Minimum On-Axis Output Not A Number!',
    'Minimum On-Axis Output Of Range!',errorflag, 0.001, 0.99);
  IF errorflag = FALSE THEN GOTO Done;

```

```

CheckRealData(RunInput.Zmax,RunInput.errormessage,
'Maximum On-Axis Output Not A Number!',
'Maximum On-Axis Output Of Range!',errorflag, 1.05, 2.00);
IF errorflag = FALSE THEN GOTO Done;

CheckRealData(RunInput.Rgmax,RunInput.errormessage,
'Maximum Off-Axis Range Not A Number!',
'Maximum Off-Axis Range Out Of Range!',errorflag, 1.1, 10.0);
IF errorflag = FALSE THEN GOTO Done;

CheckIntegerData(RunInput.RadiusMax,RunInput.errormessage,
'Maximum Off-Axis Points Not A Number!',
'Maximum Off-Axis Points Out Of Range!',errorflag, 10, 200);
IF errorflag = FALSE THEN GOTO Done;
done:
end;

begin
Xleft := 4;
Xright := Xleft + 40;
Xleft2 := Xright + 1;
Xright2 := Xleft2 + 8;
Yfirst := 4;
R.Assign(15, 75, Yfirst + 16);
TempString := 'Maximum # Spectra (Min # to 50):';
Dialog := New(PDemoDialog, Init(R, 'RunParameters'));
with Dialog do
begin
R.Assign(Xleft, 2, Xleft + 48, 3);
Insert(New(Plabel, Init(R, 'Use tab key or mouse to select data entry field', Thomas)));
R.Assign(Xleft2, Yfirst, Xright2, Yfirst + 1);
Thomas := New(PinputLine, Init(R,128));
Insert(Thomas);
R.Assign(Xleft, Yfirst, Xright, Yfirst + 1);
Insert(New(Plabel,Init(R,'Minimum # Spectra (4 to 49):',Thomas)));
R.Assign(Xleft2, Yfirst + 1, Xright2, Yfirst + 2);
Thomas := New(PinputLine, Init(R,128));
Insert(Thomas);
R.Assign(Xleft, Yfirst + 1, Xright, Yfirst + 2);
Insert(New(Plabel,Init(R,TempString,Thomas)));
R.Assign(Xleft2, Yfirst + 2, Xright2, Yfirst + 3);
Thomas := New(PinputLine, Init(R,128));
Insert(Thomas);
R.Assign(Xleft, Yfirst + 2, Xright, Yfirst + 3);
Insert(New(Plabel,Init(R,'Number On-Axis Points (100 to 400):',Thomas)));
R.Assign(Xleft2, Yfirst + 3, Xright2, Yfirst + 4);
Thomas := New(PinputLine, Init(R,128));
Insert(Thomas);
R.Assign(Xleft, Yfirst + 3, Xright, Yfirst + 4);
Insert(New(Plabel,Init(R,'Number Off-Axis Points (1 to 40):',Thomas)));
R.Assign(Xleft2, Yfirst + 4, Xright2, Yfirst + 5);
Thomas := New(PinputLine, Init(R,128));
Insert(Thomas);
R.Assign(Xleft, Yfirst + 4, Xright, Yfirst + 5);
Insert(New(Plabel,Init(R,'Radial Step Size (0.02 to 0.001):',Thomas)));
R.Assign(Xleft2, Yfirst + 5, Xright2, Yfirst + 6);
Thomas := New(PinputLine, Init(R,128));
Insert(Thomas);
R.Assign(Xleft, Yfirst + 5, Xright, Yfirst + 6);
Insert(New(Plabel,Init(R,'Min On-Axis Output (0.001 to 0.99):',Thomas)));
R.Assign(Xleft2, Yfirst + 6, Xright2, Yfirst + 7);
Thomas := New(PinputLine, Init(R,128));
Insert(Thomas);
R.Assign(Xleft, Yfirst + 6, Xright, Yfirst + 7);
Insert(New(Plabel,Init(R,'Max On-Axis Output (1.05 to 2.0):',Thomas)));
R.Assign(Xleft2, Yfirst + 7, Xright2, Yfirst + 8);
Thomas := New(PinputLine, Init(R,128));
Insert(Thomas);
R.Assign(Xleft, Yfirst + 7, Xright, Yfirst + 8);
Insert(New(Plabel,Init(R,'Max Off-Axis Range (1.1 to 10.0):',Thomas)));
R.Assign(Xleft2, Yfirst + 8, Xright2, Yfirst + 9);
Thomas := New(PinputLine, Init(R,128));
Insert(Thomas);
R.Assign(Xleft, Yfirst + 8, Xright, Yfirst + 9);
Insert(New(Plabel,Init(R,'Max Off-Axis Points (10 to 200):',Thomas)));
R.Assign(16, Yfirst + 10, 56, Yfirst + 11);
Thomas := New(PinputLine, Init(R,128));

```

```

Insert(Thomas);
R.Assign(1, yfirst + 10, 15, yfirst + 11);
Insert(New(PLabel, Init(R, 'Error Message', Thomas)));

(
    These are the escape buttons from the box. To use the values entered execute cmOK. To discard the changes
    execute cmCancel.
)

R.Assign(xleft + 9, yfirst + 12, xleft + 19, yfirst + 14);
Insert(New(PButton, Init(R, 'O-k', cmOK, bfDefault)));
R.Assign(xleft + 34, yfirst + 12, xleft + 44, yfirst + 14);
Insert(New(PButton, Init(R, 'Cancel', cmCancel, bfNormal)));

end;
REPEAT
Dialog^.SetData(RunInput);
C := DeskTop^.ExecView(Dialog);
if C <> cmCancel then Dialog^.GetData(RunInput);

(
    Check to see whether there are any errors. If an error has occurred, then do not exit the program.
)

CheckRunParameters;
UNTIL ((C = cmCancel) or (C = cmOK)) and (errorflag = TRUE);
Dispose(Dialog, Done);
end;

```

```
(      This procedure is used to input or change transducer related parameters, such as the radius of curvature, diameter,
initial on-axis power, and frequency.      )
```

```
procedure TMyApp.NewTransducer;
```

```
var
  Thomas2: PView;
  Dialog2: PDemoDialog;
  R: TRect;
  C: Word;
  errormessage : STRING;
  xleft,
  xright,
  xleft2,
  xright2,
  yfirst : BYTE;
```

```
(      This is the local procedure that checks the transducer data entries. It uses CheckIntegerData and CheckRealData
with the appropriate values.      )
```

```
Procedure CheckTransducer;
```

```
  LABEL Done;
```

```
  begin {CheckTransducer}
```

```
(      First set the error message and error flag. Then check each of the data entries starting with the diameter. If an
error occurs, set the error flag to FALSE and exit.      )
```

```
    transducer.errormessage := '';
    errorflag := TRUE;
    CheckRealData(transducer.diameter,transducer.errormessage,
'Diameter Entry Is Not A Number!',
'Diameter Entry Out Of Range!',errorflag, 0, 1);
    IF errorflag = FALSE THEN GOTO Done;
```

```
    CheckRealData(transducer.RadiusOfC,transducer.errormessage,
'Focal Length Is Not A Number!',
'Focal Length Out Of Range!',errorflag, 0, 1);
    IF errorflag = FALSE THEN GOTO Done;
```

```
    CheckRealData(transducer.frequency,transducer.errormessage,
'Frequency Is Not A Number!',
'Frequency Out Of Range!',errorflag, 0, 10);
    IF errorflag = FALSE THEN GOTO Done;
```

```
    CheckRealData(transducer.pressure,transducer.errormessage,
'Pressure Is Not A Number!',
'Pressure Out Of Range!',errorflag, 0, 2000);
```

```
  done :
  end; {CheckTransducer}
```

```
begin
```

```
  Yfirst := 2;
  Xleft := 2;
  Xright := Xleft + 34;
  Xleft2 := Xright + 1;
  Xright2 := Xleft2 + 10;
  R.Assign(5, 6, 58, 20);
  Dialog2 := New(PDemoDialog, Init(R, 'Transducer Characteristics'));
  with Dialog2^ do
  begin
    R.Assign(Xleft, Yfirst, 50, Yfirst + 1);
    Insert(New(PLabel, Init(R, 'Use Tab key or mouse to select data entry field', Thomas2)));
    R.Assign(Xleft2, Yfirst + 2, Xright2, Yfirst + 3);
    Thomas2 := New(PInputLine, Init(R,128));
    Insert(Thomas2);
    R.Assign(Xleft, Yfirst + 2, Xright, Yfirst + 3);
    Insert(New(PLabel,Init(R,'Diameter (Meters: 0 .. 1):',Thomas2)));
    R.Assign(Xleft2, Yfirst + 3, Xright2, Yfirst + 4);
    Thomas2 := New(PInputLine, Init(R,128));
    Insert(Thomas2);
    R.Assign(xleft, yfirst + 3, xright, Yfirst + 4);
    Insert(New(PLabel,Init(R,'Focal Length (Meters: 0 .. 1):',Thomas2)));
    R.Assign(Xleft2, Yfirst + 4, Xright2, Yfirst + 5);
```

```

Thomas2 := New(PInputLine, Init(R,128));
Insert(Thomas2);
R.Assign(xleft, yfirst +4, xright, Yfirst + 5);
Insert(New(PLabel,Init(R,'Initial Frequency (MHz: 0 .. 10):',Thomas2)));
R.Assign(Xleft2, Yfirst + 5, Xright2, Yfirst + 6);
Thomas2 := New(PInputLine, Init(R,128));
Insert(Thomas2);
R.Assign(xleft, yfirst + 5, xright, Yfirst + 6);
Insert(New(PLabel,Init(R,'Initial Pressure (kPa: 0 .. 2000):',Thomas2)));
R.Assign(16,Yfirst + 7, 49, Yfirst + 8);
Thomas2 := New(PInputLine, Init(R,128));
Insert(Thomas2);
R.Assign(1,Yfirst + 7, 15,Yfirst + 8);
Insert(New(PLabel,Init(R,'Error Message',Thomas2)));

(      These are the escape buttons from the box. To use the values entered execute cmOK. To discard the changes
      execute cmCancel.      )

R.Assign(10, Yfirst + 9, 20, Yfirst + 11);
Insert(New(PButton, Init(R, 'O-k', cmOK, bfDefault)));
R.Assign(35, Yfirst + 9, 45, Yfirst + 11);
Insert(New(PButton, Init(R, 'Cancel', cmCancel, bfNormal)));

end;
REPEAT
  Dialog2^.SetData(Transducer);
  C := DeskTop^.ExecView(Dialog2);
  if C <> cmCancel then Dialog2^.GetData(Transducer);
(      Check to see whether there are any errors. If an error has occurred, then do not exit the program.      )

  CheckTransducer;
  UNTIL (((C = cmCancel) or (C = cmOK)) and (errorflag = TRUE));
  Dispose(Dialog2,Done);
end;

```

```

{      This procedure is used to select the type and source of the initial pressure distribution at the face of the transducer.
      The options allow the user to enter the data or select a file.
}

procedure TMyApp.SelectBoundary;
var
  Thomas2: PView;
  Dialog2: PDemoDialog;
  R: TRect;
  C: Word;
  ErrorMessage : STRING;
  xleft,
  xright,
  xleft2,
  xright2,
  XleftB1,
  YleftB1,
  XRightB1,
  YRightB1,
  XleftB2,
  XRightB2,
  YleftB2,
  YRightB2,
  yfirst : BYTE;
  textfile : TEXT;

begin
  yfirst := 2;
  Xleft := 2;
  XleftB1 := 6;
  YleftB1 := 5;
  XRightB1 := XleftB1 + 14;
  YRightB1 := YleftB1 + 3;
  XleftB2 := XRightB1 + 6;
  YleftB2 := YleftB1;
  XRightB2 := XleftB2 + 18;
  YRightB2 := YleftB2 + 2;
  Xright := Xleft + 34;
  Xleft2 := Xright + 1;
  Xright2 := Xleft2 + 10;
  R.Assign(5, 6, 55, 18);
  Dialog2 := New(PDemoDialog, Init(R, 'Transducer Pressure Distribution Options'));
  with Dialog2 do
    begin
      R.Assign(Xleft, Yfirst, 46, Yfirst + 1);
      Insert(New(PLabel, Init(R, 'To Select Option, Press Highlighted Letter', Thomas2)));

      {      This set of radio buttons allow the selection of the values used in a previous run, a uniform distribution, or a set of
            data values contained in a file.
      }

      R.Assign(XleftB1, YleftB1, XRightB1, YRightB1);
      Thomas2 := New(PRadioButtons, Init(R,
        NewSItem('P~revious',
        NewSItem('U~niform',
        NewSItem('N~ew',
        nil)))
      ));
      Insert(Thomas2);

      R.Assign(XleftB1-4, YleftB1 - 1, XRightB1+4, YleftB1);
      Insert(New(PLabel, Init(R, 'Pressure Distribution', Thomas2)));

      {      This allows the selection of a previous file or the creation of new file.
      }

      R.Assign(XleftB2, YleftB2, XRightB2, YRightB2);
      Thomas2 := New(PRadioButtons, Init(R,
        NewSItem('Use ~F~ile',
        NewSItem('~E~nter Data',
        nil)))
      ));
      Insert(Thomas2);

      R.Assign(XleftB2 + 4, YleftB2- 1, XRightB2, YleftB2);
      Insert(New(PLabel, Init(R, 'Source', Thomas2)));
    end
  end
end

```

```
(      These are the escape buttons from the box. To use the values entered execute cmOK. To discard the changes  
execute cmCancel.      )
```

```
R.Assign(7, Yfirst + 7, 17, Yfirst + 9);  
Insert(New(PButton, Init(R, 'O~k', cmOK, bfDefault)));  
R.Assign(29, Yfirst + 7, 39, Yfirst + 9);  
Insert(New(PButton, Init(R, 'Cancel', cmCancel, bfNormal)));  
  
end;  
REPEAT  
  Dialog2^.SetData(BoundaryChoice);  
  C := DeskTop^.ExecView(Dialog2);  
  if C <> cmCancel THEN Dialog2^.GetData(BoundaryChoice);  
UNTIL ((C = cmCancel) or (C = cmOK));  
Dispose(Dialog2, Done);  
end;
```



```
{      This procedure is used to enter and check the name associated with an existing data file.      }
```

```
procedure TMyApp.EnterFileName;
var
```

```
  Thomas2: PView;
  Dialog2: PDemoDialog;
  R: TRect;
  C: Word;
  errorMessage : STRING;
  xleft,
  xright,
  xleft2,
  xright2,
  ButtonLength,
  OKXlocation,
  OKYlocation,
  CXlocation,
  CYlocation,
  yfirst : BYTE;
  textfile : TEXT;
  DirInfo : SearchRec;
```

```
begin {EnterFileName}
```

```
  Xleft := 2;
  Xright := Xleft + 22;
  Yfirst := 2;
  Xleft2 := Xright + 2;
  Xright2 := Xleft2 + 30;
  ButtonLength := 10;
  OKXlocation := 10;
  CXlocation := 35;
  OKYlocation := 6;
  CYlocation := OKYlocation;
  R.Assign(5, 6, 65, 15);
  Dialog2 := New(PDemoDialog, Init(R, 'Pressure Distribution File Name'));
  with Dialog2^ do
```

```
    begin
      R.Assign(Xleft2, Yfirst, Xright2, Yfirst+1);
      Thomas2 := New(PInputLine, Init(R, 128));
      Insert(Thomas2);
      R.Assign(Xleft, Yfirst, Xright, Yfirst + 1);
      Insert(New(PLabel, Init(R, 'File Name (<40 Char)', Thomas2)));
      R.Assign(Xleft2, Yfirst+2, Xright2, Yfirst+3);
      Thomas2 := New(PInputLine, Init(R, 128));
      Insert(Thomas2);
      R.Assign(Xleft, Yfirst+2, Xright, Yfirst + 3);
      Insert(New(PLabel, Init(R, 'Error Message', Thomas2)));
    end;
```

```
{      These are the escape buttons from the box. To use the values entered execute cmOK. To discard the changes
      execute cmCancel.      }
```

```
  R.Assign(OKXlocation, OKYlocation, OKXlocation + ButtonLength, OKYlocation + 2);
  Insert(New(PButton, Init(R, 'O-k', cmOK, bfDefault)));
  R.Assign(CXlocation, CYlocation, CXlocation + ButtonLength, CYlocation + 2);
  Insert(New(PButton, Init(R, 'Cancel', cmCancel, bfNormal)));
```

```
end;
```

```
REPEAT
```

```
  Dialog2^.SetData(FileName);
  C := Desktop^.ExecView(Dialog2);
  if C <> cmCancel then
    begin
      skipflag := FALSE;
      Dialog2^.GetData(FileName);
      checkfilename(filename.name, filename.errorMessage);
      IF (C = cmOK) and (FileName.Name = '') THEN errorflag := FALSE
        ELSE
          IF Errorflag <> FALSE THEN
            begin
              FindFirst(filename.name, AnyFile, DirInfo);
              IF DosError <> 0 THEN
                begin
                  errorflag := FALSE;
                  filename.errorMessage := 'File '+filename.name+ ' Not Found!';
                end;
            end;
          end;
    end;
```

```
end;  
end           else  
begin  
    errorflag := TRUE;  
    skipflag  := TRUE;  
end;  
  
UNTIL (((C = cmCancel) or (C = cmOK)) and (errorflag = TRUE));  
IF C = cmCancel THEN BoundaryChoice.RadioButtonDataA := 0;  
Dispose(Dialog2,Done);  
end; {EnterFileName}
```

```
(      This procedure is used to enter the name of a data file which is to be created, the number of data points which will
      be contained in the file, and check the file name to make sure it conforms of DOS standards.      )
```

```
procedure TMyApp.EnterFileName2;
var
```

```
  Thomas2: PView;
  Dialog2: PDemoDialog;
  R: TRect;
  C: Word;
  errorMessage : STRING;
  xleft,
  xright,
  xleft2,
  xright2,
  ButtonLength,
  OKXlocation,
  OKYlocation,
  CXlocation,
  CYlocation,
  yfirst : BYTE;
  textfile : TEXT;
```

```
Procedure CheckNumberPoints;
```

```
(      This procedure checks the number of points to make sure it is an integer and within range.      )
```

```
  LABEL Done;
```

```
  begin {CheckNumberPoints}
```

```
    filename2.errorMessage := '';
    errorflag := TRUE;
    CheckIntegerData(filename2.NumberPoints,filename2.errorMessage,
      'Number Of Points Must Be > 0',
      'Number Of Points Out Of Range!',errorflag, 0, 100);
  end; {CheckNumberPoints}
```

```
begin {EnterFileName2}
```

```
  Xleft := 2;
  Xright := Xleft + 22;
  Yfirst := 2;
  Xleft2 := Xright + 2;
  Xright2 := Xleft2 + 30;
  ButtonLength := 10;
  OKXlocation := 10;
  CXlocation := 35;
  OKYlocation := 7;
  CYlocation := OKYlocation;
  R.Assign(5, 6, 65, 16);
  Dialog2 := New(PDemoDialog, Init(R, 'New Pressure Distribution File Name'));
  with Dialog2^ do
  begin
    R.Assign(Xleft2, Yfirst, Xright2, Yfirst+1);
    Thomas2 := New(PInputLine, Init(R,128));
    Insert(Thomas2);
    R.Assign(Xleft, Yfirst, Xright, Yfirst + 1);
    Insert(New(PLabel,Init(R,'F-ile Name (<40 Char)',Thomas2)));
    R.Assign(Xleft2, Yfirst+1, Xright2, Yfirst+2);
    Thomas2 := New(PInputLine, Init(R,128));
    Insert(Thomas2);
    R.Assign(Xleft, Yfirst+1, Xright, Yfirst + 2);
    Insert(New(PLabel,Init(R,'N-umber of points',Thomas2)));

    R.Assign(Xleft2, Yfirst+3, Xright2, Yfirst+4);
    Thomas2 := New(PInputLine, Init(R,128));
    Insert(Thomas2);
    R.Assign(Xleft, Yfirst+3, Xright, Yfirst + 4);
    Insert(New(PLabel,Init(R,'Error Message',Thomas2)));
  end;
```

```
(      These are the escape buttons from the box. To use the values entered execute cmOK. To discard the changes
      execute cmCancel.      )
```

```
  R.Assign(OKXlocation, OKYlocation, OKXlocation + ButtonLength, OKYlocation + 2);
  Insert(New(PButton, Init(R, 'O-k', cmOK, bfDefault)));
  R.Assign(CXlocation, CYlocation, CXlocation + ButtonLength, CYlocation + 2);
  Insert(New(PButton, Init(R, 'Cancel', cmCancel, bfNormal)));
```

```

end;
REPEAT
  skipflag := FALSE;
  Dialog2^.SetData(FileName2);
  C := DeskTop^.ExecView(Dialog2);
  if C <> cmCancel then
    begin
      Dialog2^.GetData(FileName2);
      checkfilename(filename2.name,filename2.errormessage);

      IF ((C = cmOK) and (FileName2.Name = '')) THEN
        begin
          errorflag := FALSE;
          filename2.errormessage := 'No File Name Entered!';
        end
        ELSE
          IF errorflag = TRUE THEN CheckNumberPoints;
        end
        else
          begin
            errorflag := TRUE;
            skipflag := true;
          end;
        end;
      UNTIL ((C = cmCancel) or ((C = cmOK) and (errorflag = TRUE)));
      IF C = cmCancel THEN BoundaryChoice.RadioButtonDataA := 0;
      Dispose(Dialog2,Done);
    end; {EnterFileName2}

```

```

{      This procedure is used for the off-axis data entry.      }

procedure TMyApp.OffAxisData;
var
  Thomas2: PView;
  Dialog2: PDemoDialog;
  R: TRect;
  C: Word;
  tempval,
  errormessage : STRING;
  xleft,
  xright,
  xleft2,
  xright2,
  yfirst : BYTE;

{      This is the local procedure that checks the transducer data entries. It uses CheckIntegerData and CheckRealData
      with the appropriate values.      }

Procedure CheckOffAxisData;

VAR
  minval,
  maxval :SINGLE;

LABEL Done;

begin {CheckOffAxisData}

{      First set the error message and error flag. Then check each data entry. Since this procedure is called each time the
      off axis index changes. If an error occurs, set the error flag to FALSE and exit.      }

  ZU[offaxisindex].errormessage := '';
  errorflag := TRUE;
  VAL(ZU[offaxisindex - 1].location,minval,code);
  VAL(RunInput.Zmax,maxval,code);
  CheckRealData(ZU[offaxisindex].location,ZU[offaxisindex].errormessage,
  'Off-Axis Entry Is Not A Number!', 'Previous Entry '+
  ZU[offaxisindex - 1].location + ' Entry Out Of Range!',errorflag, minval, maxval);
  IF errorflag = FALSE THEN GOTO Done;
  done :

  end; {CheckOffAxisData}

begin
  Yfirst := 2;
  Xleft := 5;
  Xright := Xleft + 38;
  Xleft2 := Xright + 1;
  Xright2 := Xleft2 + 10;
  STR(offaxisindex,tempval);
  R.Assign(5, 6, 65,17);
  Dialog2 := New(PDemoDialog, Init(R, 'Off Axis Location ' + tempval));
  with Dialog2 do
  begin
    R.Assign(Xleft, Yfirst, Xleft + 50, Yfirst + 1);
    Insert(New(PLabel, Init(R, 'Use Tab key or mouse to select data entry field', Thomas2)));
    R.Assign(Xleft2, Yfirst + 2, Xright2, Yfirst + 3);
    Thomas2 := New(PInputLine, Init(R,128));
    Insert(Thomas2);
    R.Assign(Xleft, Yfirst + 2, Xright, Yfirst + 3);
    Insert(New(PLabel,Init(R,'Output Point (> previous value < '+ RunInput.Zmax +'):',Thomas2)));
    R.Assign(16,Yfirst + 4,59, Yfirst + 5);
    Thomas2 := New(PinputLine, Init(R,128));
    Insert(Thomas2);
    R.Assign(1,Yfirst + 4,15,Yfirst + 5);
    Insert(New(PLabel,Init(R,'Error Message',Thomas2)));

{      These are the escape buttons from the box. To use the values entered execute cmOK. To discard the changes
      execute cmCancel.      }

    R.Assign(10, Yfirst + 6, 20, Yfirst + 8);
    Insert(New(PButton, Init(R, 'O-k', cmOK, bfDefault)));
    R.Assign(35, Yfirst + 6, 45, Yfirst + 8);
    Insert(New(PButton, Init(R, 'Cancel', cmCancel, bfNormal)));
  end;
end;

```

```

REPEAT
  Dialog2^.SetData(ZU[OffAxisIndex]);
  C := DeskTop^.ExecView(Dialog2);
  if C <> cmCancel then Dialog2^.GetData(ZU[OffAxisIndex]);
{    Check to see whether there are any errors. If an error has occurred, then do not exit the program.    }

  CheckOffAxisData;
  UNTIL (((C = cmCancel) or (C = cmOK)) and (errorflag = TRUE));
  Dispose(Dialog2,Done);
end;

```

```

{      This procedure checks each location and pressure pair to make sure they are within range.      }

procedure TMyApp.BoundaryAxisData;
VAR
  Thomas2: PView;
  Dialog2: PDemoDialog;
  R: TRect;
  C: WORD;
  tempval,
  errormessage : STRING;
  xleft,
  xright,
  xleft2,
  xright2,
  yfirst : BYTE;

procedure CheckBoundaryAxisData;

{      This procedure checks the normalized pressure or the radial input point to assure that the normalized pressure is
      less than 1.0 and that the radial input point is less than the transducer's transverse radius.      }

VAR
  minval,
  maxval :SINGLE;

  LABEL Done;

begin {CheckBoundaryAxisData}

  BoundaryChoiceValues[offaxisindex].errormessage := '';
  errorflag := TRUE;
  minval := 0;
  VAL(Transducer.Diameter,maxval,code);
  maxval := maxval/2.0;
  CheckRealData(BoundaryChoiceValues[offaxisindex].location,
  BoundaryChoiceValues[offaxisindex].errormessage,
  'Off-Axis Location Entry Is Not A Number!',
  'Location ' + BoundaryChoiceValues[offaxisindex].location+
  ' Out Of Range!', errorflag, minval, maxval);
  IF errorflag = FALSE THEN GOTO Done;

  minval := 0;
  maxval := 1;
  CheckRealData(BoundaryChoiceValues[offaxisindex].NormalizedP,
  BoundaryChoiceValues[offaxisindex].errormessage,
  'Pressure Is Not A Number!',
  'Pressure Entry Out Of Range!', errorflag, minval, maxval);
  IF errorflag = FALSE THEN GOTO Done;

  done :
end; {CheckBoundaryAxisData}

begin
  Yfirst := 2;
  Xleft := 8;
  Xright := Xleft + 28;
  Xleft2 := Xright + 1;
  Xright2 := Xleft2 + 10;
  STR(offaxisindex + 1,tempval);
  R.Assign(5, 6, 65,18);
  Dialog2 := New(PDemoDialog, Init(R, 'Pressure Distribution Location - ' + tempval));
  WITH Dialog2 DO
  begin
    R.Assign(Xleft-3, Yfirst, Xleft + 50, Yfirst + 1);
    Insert(New(PLabel, Init(R, 'To Change The Value, Press Highlighted Letter', Thomas2)));
    R.Assign(Xleft2, Yfirst + 2, Xright2, Yfirst + 3);
    Thomas2 := New(PInputLine, Init(R,128));
    Insert(Thomas2);
    R.Assign(Xleft, Yfirst + 2, Xright, Yfirst + 3);
    Insert(New(PLabel,Init(R,'Radial -P-oint (#)',Thomas2)));
    R.Assign(Xleft2, Yfirst + 3, Xright2, Yfirst + 4);
    Thomas2 := New(PInputLine, Init(R,128));
    Insert(Thomas2);
  end
end

```

```

R.Assign(Xleft, Yfirst + 3, Xright, Yfirst + 4);
Insert(New(Plabel, Init(R, 'Normalized Pressure', Thomas2)));
R.Assign(16, Yfirst + 5, 59, Yfirst + 6);
Thomas2 := New(PinputLine, Init(R, 128));
Insert(Thomas2);
R.Assign(1, Yfirst + 5, 15, Yfirst + 6);
Insert(New(Plabel, Init(R, 'Error Message', Thomas2)));

(
    These are the escape buttons from the box. To use the values entered execute cmOK. To discard the changes
    execute cmCancel.
)

R.Assign(10, Yfirst + 7, 20, Yfirst + 9);
Insert(New(PButton, Init(R, 'O~k', cmOK, bfDefault)));
R.Assign(35, Yfirst + 7, 45, Yfirst + 9);
Insert(New(PButton, Init(R, 'Cancel', cmCancel, bfNormal)));

end;
REPEAT
    Dialog2^.SetData(BoundaryChoiceValues[OffAxisIndex]);
    C := DeskTop^.ExecView(Dialog2);
    IF C <> cmCancel THEN
        Dialog2^.GetData(BoundaryChoiceValues[OffAxisIndex]);
        CheckBoundaryAxisData;
    UNTIL ((C = cmCancel) OR (C = cmOK)) AND (errorflag = TRUE));
    Dispose(Dialog2, Done);
end;

```



```

procedure TMyApp.NewWindow;
var
  Window: PDemoWindow;
  R: TRect;
begin
  Inc(WinCount);
  R.Assign(0, 0, 45, 13);
  R.Move(Random(34), Random(11));
  Window := New(PDemoWindow, Init(R, 'Demo Window', WinCount));
  DeskTop.Insert(Window);
end;

var
  MyApp: TMyApp;

(      This procedure is used to initialize the radio button choices and the file names.      )

procedure InitiateBoundary_FileName;
begin
  WITH BoundaryChoice DO
  begin
    RadioButtonDataA := 0;
    RadioButtonDataB := 0;
  end;
  WITH FileName DO
  begin
    Name := '';
    ErrorMessage := '';
  end;
  WITH FileName2 DO
  begin
    Name := '';
    NumberPoints := '';
    ErrorMessage := '';
  end;
end;

```

```

{      This procedure saves the parameter values selected for use as defaults for the next run.      }

procedure WriteDefault;

  VAR
    textfile : TEXT;

  begin {WriteDefault}
    Assign(textfile,'Default.dat');
    Rewrite(textfile);
    With Transducer do
      begin
        Writeln(textfile,Diameter);
        Writeln(textfile,RadiusOfC);
        Writeln(textfile,frequency);
        Writeln(textfile,pressure);
      end;
    With RunInput Do
      begin
        Writeln(textfile,MINM);
        Writeln(textfile,MAXM);
        Writeln(textfile,Npoints);
        Writeln(textfile,NDpoints);
        Writeln(textfile,DeltaR);
        Writeln(textfile,Zmin);
        Writeln(textfile,Zmax);
        Writeln(textfile,Rgmax);
        Writeln(textfile,RadiusMax);
      end;
    For n := 0 to 50 do
      WITH ZU[n] Do
        begin
          Writeln(textfile,location);
        end;
        Writeln(textfile,NumberBoundaryPoints);
        FOR n := 0 TO NumberBoundaryPoints - 1 DO
          begin
            VAL(BoundaryChoiceValues[n].location,temp1,code);
            VAL(BoundaryChoiceValues[n].NormalizedP,temp2,code);
            Writeln(textfile,Temp1:12:8);
            Writeln(textfile,Temp2:12:8);
          end;
        Close(textfile);
      end; {WriteDefault}

```

```

(      This procedure reads the parameter values selected for use as defaults for the next run.      )

procedure ReadDefault;

  VAR
    textfile : TEXT;

  begin {ReadDefault}
    Assign(textfile,'Default.dat');
    Reset(textfile);
    With Transducer do
      begin
        Readln(textfile,Diameter);
        Readln(textfile,RadiusOfC);
        Readln(textfile,frequency);
        Readln(textfile,pressure);
        errormessage := '';
      end;
    With RunInput Do
      begin
        Readln(textfile,MINM);
        Readln(textfile,MAXM);
        Readln(textfile,Npoints);
        Readln(textfile,NDpoints);
        Readln(textfile,DeltaR);
        Readln(textfile,Zmin);
        Readln(textfile,Zmax);
        Readln(textfile,Rgmax);
        Readln(textfile,RadiusMax);
        errormessage := '';
      end;
    For n := 0 to 50 do
      WITH ZU[n] Do
        begin
          Readln(textfile,location);
          errormessage := '';
        end;
      READLN(textfile,NumberBoundaryPoints);
      FOR n := 0 TO NumberBoundaryPoints - 1 DO
        begin
          READLN(textfile,BoundaryChoiceValues[n].location);
          READLN(textfile,BoundaryChoiceValues[n].NormalizedP);
          BoundaryChoiceValues[n].errormessage := '';
        end;
      FOR n := NumberBoundaryPoints TO 100 DO
        WITH BoundaryChoiceValues[n] DO
          begin
            location      := '';
            NormalizedP   := '';
            errormessage  := '';
          end;
        Close(textfile);
      end; {ReadDefault}

```

```
{      This procedure writes the input data file for the LFOCUS run.
```

```
}
```

```
procedure WriteInputData;
```

```
VAR
  textfile      : TEXT;
  tempstring    : STRING;
  tempval,
  radiusmaxval,
  deltarOut,
  radiusval     : DOUBLE;
  tempint       : INTEGER;

begin {WriteInputData}
  Assign(textfile,'Input.dat');
  Rewrite(textfile);
  Writeln(textfile,'1');
  Writeln(textfile,'1.0d-6');
  Writeln(textfile,RunInput.RadiusMax);
  Writeln(textfile,RunInput.Rgmax+'DO');
  Writeln(textfile,'2.5d-14');
  Writeln(textfile,Transducer.pressure+'D+3');
  Writeln(textfile,'9.98d+2');
  Writeln(textfile,'5.500');
  Writeln(textfile,Transducer.RadiusOfC+'DO');
  VAL(Transducer.Diameter,tempval,code);
  tempval := tempval/2.0;
  STR(tempval:9:6,tempstring);
  Writeln(textfile,tempstring+'DO');
  Writeln(textfile,RunInput.DeltaR+'DO');
  Writeln(textfile,RunInput.Zmin+'DO');
  Writeln(textfile,RunInput.Zmax+'DO');
  Writeln(textfile,RunInput.Npoints);
  Writeln(textfile,RunInput.NDpoints);
  VAL(RunInput.NDpoints,tempint,code);
  For n := 1 to tempint Do
  WITH ZU[n] Do
  begin
    Writeln(textfile,location+'DO');
  end;
  With RunInput Do
  begin
    Writeln(textfile,MINM);
    Writeln(textfile,MAXM);
  end;
  Writeln(textfile,'1.492D+3');
  Writeln(textfile,Transducer.frequency+'D+6');
  Writeln(textfile,NumberBoundaryPoints);
  FOR n := 0 TO NumberBoundaryPoints - 1 DO
  begin
    VAL(BoundaryChoiceValues[n].location,temp1,code);
    VAL(BoundaryChoiceValues[n].NormalizedP,temp2,code);
    Writeln(textfile,Temp1:12:8,' ',Temp2:12:8);
  end;
  Close(textfile);
end; {WriteInputData}
```

```
{      This procedure writes a file which contains the location, normalized pressure pair that is used to describe the initial
        amplitude distribution at the face of the transducer.      }
```

```
procedure WriteBoundaryFile;
```

```
VAR
```

```
  textfile : TEXT;
```

```
  n        : INTEGER;
```

```
  Temp1,
```

```
  Temp2    : DOUBLE;
```

```
begin {WriteBoundaryFile}
```

```
  Assign(textfile,FileName2.name);
```

```
  Rewrite(textfile);
```

```
  Writeln(textfile,FileName2.NumberPoints);
```

```
  FOR n := 0 TO NumberBoundaryPoints - 1 DO
```

```
    begin
```

```
      VAL(BoundaryChoice.Values[n].location,temp1,code);
```

```
      VAL(BoundaryChoice.Values[n].NormalizedP,temp2,code);
```

```
      Writeln(textfile,Temp1:12:8);
```

```
      Writeln(textfile,Temp2:12:8);
```

```
    end;
```

```
  CLOSE(textfile);
```

```
end; {WriteBoundaryFile}
```

```
begin {Menu}
```

```
  ZU[0].location := '0.0';
```

```
  ReadDefault;
```

```
  InitiateBoundary_FileName;
```

```
  errorflag := TRUE;
```

```
  MyApp.Init;
```

```
  MyApp.Run;
```

```
  MyApp.Done;
```

```
  WriteDefault;
```

```
  IF BoundaryChoice.RadioButtonDataA = 2 THEN
```

```
    If BoundaryChoice.RadioButtonDataB = 1 THEN WriteBoundaryFile;
```

```
  WriteInputData;
```

```
end. {Menu}
```

APPENDIX C  
LFOCUS.F  
PROGRAM LISTING

Some additional terms used in the program

ZMIN	- Minimum Z value for output purposes
ZMAX	- Maximum Z value for output purposes
RGMAX	- Maximum grid dimension
Rgmin	- Minimum grid dimension
Rmax	- Maximum R value
THRESHOLD	- Amplitude threshold when spectral term is added
MINM	- Minimum number of spectral terms in a calculation
MAXM	- Maximum number of spectral terms in the calculation
NPOINTS	- Number of normal longitudinal output points
NDPOINTS	- Number of detailed longitudinal output points
Number_BP	- Number of transverse boundary points (including 0)
TPOINTS	- Total number of output points
IOUTMAX	- Maximum transverse index for output
MARRAYINDEX	- Maximum array index
IMAX	- Maximum transverse array index
IMAX1	- IMAX - 1
IMAX4	- IMAX - 2
IMAXMIN	- Starting transverse array index
IMAXMAX	- Maximum transverse array index
RESTART	- Flag for restart after a controlled exit
K	- Counter for on-axis output
L	- Counter for off-axis output
COUNTER	- Local counter for fixing output points
CASE	- The current analysis case
NSTEP	- Step number
Pi	- $\pi$
TWOPI	- $2.0 * \pi$
P0	- Initial On-axis pressure (kPa)
Omega	- Angular fundamental frequency
BoverA	- Nonlinearity parameter (B/A)
Bover2A	- $1 + \text{BoverA}/2$
Number_RP	- Number of uniformly spaced radial points
NewDeltaR	- Radial step size in meters

```

DOUBLE PRECISION K1, K2, K3, KN1, KN2, KN3, KN4
DOUBLE PRECISION ZMIN, ZMAX, Threshold, Pi, TwoPi
DOUBLE PRECISION P0, Omega, BoverA, Bover2A, Rmax, Rgain, Rgmax
DOUBLE PRECISION OldDeltaR, NewDeltaR
INTEGER CASE, MAXM, MINM, RESTART, IOUTMAX, NPOINTS, NDPOINTS, Number_BP
INTEGER TPOINTS, COUNTER, IMAX, I, NSTEP, K, L, M, IMAXMIN
INTEGER IMAXMAX, IMAX4, IMAX1, Number_RP
LOGICAL NEWTEST

```

This is the first set of COMMON blocks

```

COMMON /ALL/ NEWTEST
COMMON /CONSTANTS/ A, D, Freq, CO, TwoPi, Pi
COMMON /KVALUE/ K1, K2, K3, KN1, KN2, KN3, KN4

```

This common is used for indices

```

COMMON /INDEXES/ IMAX, M, IMAX1

```

This common is used by NEXT and the main program

```

COMMON /NEXTC/ DeltaR, DeltaZ, Rayleigh, Ld, AlphaD, Rmax

```

At this point, take the maximum and minimum Z values and the specified detailed output points and determine the points to output data.

```

* The logic is simple. First calculate the location of each normal output
* point. Then make a loop and use the loop to populate the ZOUT array. As
* the array is populated, check to see if a detailed output point has been
* reached. If so, add it to the array
*
* Before reading the input data write one as the restart flag so that the
* restart option can be exercised, if desired.
*
OPEN(5,FILE = 'RESTART')
READ(5,*) Restart
CLOSE(5)
*
* Set the maximum array index
*
MARRAYINDEX = 4000
*
* If restarting execution, reset the current parameter values to the ones present
* when the run was terminated.
*
IF (RESTART.EQ.1) THEN
*
* If restarting, read the relevant parameters.
*
OPEN(5,FILE='TEMP1.DAT')
READ(5,*) Case
READ(5,*) Threshold
READ(5,*) IoutMax
READ(5,*) Rgmax
READ(5,*) Rgmin
READ(5,*) Rmax
READ(5,*) Alpha0
READ(5,*) Alpha
READ(5,*) AlphaD
READ(5,*) P0
READ(5,*) Ro0
READ(5,*) BoverA
READ(5,*) Bover2A
READ(5,*) D
READ(5,*) A
READ(5,*) DeltaR
READ(5,*) DeltaZ
READ(5,*) Zmin
READ(5,*) Zmax
READ(5,*) Z
READ(5,*) K
READ(5,*) L
READ(5,*) NSTEP
READ(5,*) IMAXMAX
READ(5,*) IMAXMIN
READ(5,*) IMAX
READ(5,*) IMAX4
READ(5,*) K1
READ(5,*) K2
READ(5,*) K3
READ(5,*) KN1
READ(5,*) KN2
READ(5,*) KN3
READ(5,*) KN4
READ(5,*) Npoints
READ(5,*) NDpoints
READ(5,*) Number BP
READ(5,*) Tpoints
DO 299 I = 1, NDpoints
  READ(5,*) ZU(I)
299 CONTINUE
DO 298 I = 0, Number BP - 1
  READ(5,*) BoundaryP(0,I),BoundaryP(1,I)
298 CONTINUE
READ(5,*) MinM
READ(5,*) M
READ(5,*) MaxM
READ(5,*) C0
READ(5,*) Freq

```



```

      READ(5,*) Omega
      READ(5,*) Rayleigh
      READ(5,*) Ld
      READ(5,*) P1
      READ(5,*) TwoPi
    .
    .
    .
    Now, read the initially calculated output array.
    .
    .
    DO 606 I = 1, Tpoints
      READ(5,*) ZOUT(I)
606  CONTINUE
      CLOSE(5)
    .
    .
    Next, read the arrays used in the calculation G and H.
    .
    .
    CALL READTEMP(G, H, MAXM, IMAXMAX)
    .
    .
    Now, open the old output files from the terminated run, set the pointer
    to the end of the file, and return to the program.
    .
    .
334  OPEN(11,FILE='AMPZ',STATUS='OLD')
      READ(11,*,END=335) DUMMY
      GO TO 334
335  OPEN(12,FILE='PHASEZ',STATUS='OLD')
      READ(12,*,END=336) DUMMY
      GO TO 335
336  OPEN(13,FILE='AMPZR',STATUS='OLD')
      READ(13,*,END=337) DUMMY
      GO TO 336
337  OPEN(14,FILE='PHASEZR',STATUS='OLD')
      READ(14,*,END=338) DUMMY
      GO TO 337
338  BACKSPACE(11)
      BACKSPACE(12)
      BACKSPACE(13)
      BACKSPACE(14)
      DUMMY = DUMMY * 1.0
    .
    .
    Jump to program execution.
    .
    .
    GOTO 333
  ENDIF
    .
    .
    This is not a restart, therefore open the menu program. But first set
    restart to 1 for future reference.
    .
    .
    OPEN (5,FILE = 'RESTART')
    Restart = 1
    WRITE(5,397) Restart
397  FORMAT(I4)
    CLOSE(5)
    .
    .
    Execute the menu program.
    .
    .
    CALL SYSTEM('Menu.exe')
    .
    .
    This is the primary code input section. For the integrated Pascal & FORTRAN
    code, the file INPUT.DAT is the transfer point between the two codes.
    .
    .
    OPEN(5,FILE = 'INPUT.DAT')
    READ(5,*) Case
    READ(5,*) Threshold
    READ(5,*) IoutMax
    READ(5,*) Rgmax
    READ(5,*) Alpha0
    READ(5,*) P0
    READ(5,*) Ro0
    READ(5,*) BoverA
    READ(5,*) D
    READ(5,*) A
    READ(5,*) DeltaR

```

```

      READ(5,*) Zmin
      READ(5,*) Zmax
      READ(5,*) Npoints
      READ(5,*) NDpoints
      Do 399 I = 1, NDpoints
        READ(5,*) ZU(I)
399    CONTINUE
      READ(5,*) MinM
      READ(5,*) MaxM
      READ(5,*) CO
      READ(5,*) Freq
      READ(5,*) Number_BP
      Do 297 I = 0, Number_BP - 1
        READ(5,*) BoundaryP(0,I),BoundaryP(1,I)
297    CONTINUE
      .
      .   Close the file and calculate some of the parameters
      .
      CLOSE(5)
      .
      .   Set the boundary region Rgmin to 10% greater than the physical edge
      .   of the transducer.
      .
      Rgmin    = 1.1D0
      .
      .   Calculate B/2A using B/A
      .
      Bover2A  = 1.0D0 + (BoverA/2.0D0)
      .
      .   Set the values of Pi and 2 Pi for the program
      .
      Pi       = 2.0D0 * DASIN(1.0D0)
      TwoPi    = 2.0D0 * Pi
      .
      .   Set Omega and the attenuation terms
      .
      Omega    = TwoPi * Freq
      Alpha    = Alpha0 * (Freq**2)
      AlphaD   = Alpha * D
      .
      .   Set the total number of points
      .
      TPOINTS  = NPOINTS + NDPOINTS
      .
      .   Now open the output files
      .
      OPEN(11,File = 'AMPZ')
      OPEN(12,File = 'PHASEZ')
      OPEN(13,FILE = 'AMPZR')
      OPEN(14,FILE = 'PHASEZR')
      .
      .   To identify the output later include the input data a file header.
      .
      DO 237 I = 1,14
        CALL HEADER(I,Case,D,A,P0,DeltaR,Zmin,Zmax,IoutMax,Npoints,NDpoints,Number_BP,Tpoints,
          ZU,MinM,MaxM,Freq,BoundaryP)
237    CONTINUE
      .
      .   Set Z to ZMIN, COUNTER to 1, and populate the output point array.
      .
      DUMMY = (ZMAX - ZMIN)/NPOINTS
      Z = ZMIN
      COUNTER = 1
      DO 10 I = 1, TPOINTS
        Z = Z + DUMMY
        IF ((Z.GE.ZU(COUNTER)).AND.(COUNTER.LE.NDPOINTS)) THEN
          Z = Z - DUMMY
          ZOUT(I) = ZU(COUNTER)
          COUNTER = COUNTER + 1
        ELSE

```

```

      ZOUT(I) = Z
    ENDIF
10  CONTINUE
    .
    .   Now initialize a number of program parameters.
    .
    .   First, calculate the K values used in the differencing scheme.
    .
    K1 = -1.000/12.000
    K2 = 16.000/12.000
    K3 = -30.000/12.000
    KN1 = 1.000/90.000
    KN2 = -1.000 * ((1.000/12.000) + (2.000/30.000))
    KN3 = (16.000/12.000) + (15.000/90.000)
    KN4 = -1.000 * ((30.000/12.000) + (2.000/9.000))
    .
    .   Then the rest
    .
    IMAXMAX = INT((Rgmax/DeltaR) + 1.00-5)
    .
    .   This keeps the data entry errors from blowing up the code.
    .
    IF (IMAXMAX.GT.MARRAYINDEX) THEN
      IMAXMAX = MARRAYINDEX
    ENDIF
    .
    .   Continue with the calculation.
    .
    IMAXMIN = INT((Rgmin/DeltaR) + 1.0d-5)
    IMAX = IMAXMIN
    IMAX4 = IMAX - 4
    K = 1
    L = 1
    NSTEP = 0
    Rayleigh = Omega * A * A / (2.000 * C0)
    .
    .   For later use save the initial value of DeltaR.
    .
    OldDeltaR = DeltaR
    .
    DeltaR = DeltaR * DSQRT(Rayleigh/D)
    Rmax = DSQRT(Rayleigh/D)
    .
    .   Use 0.4 in the DeltaZ conversion process to make the calculations more stable.
    .
    DeltaZ = 0.4d0 * (DeltaR ** 2)
    Z = -DeltaZ
    .
    .   Calculate the initial discontinuity distance.
    .
    Ld = Ro0 * (C0**3) / (Bover2A * Omega * P0)
    M = Minm
    .
    .   Now run the initialization programs. Remember the initialization has to
    .   be at the maximum grid points. First set the transverse boundary condition.
    .
    CALL SET_BOUNDARY(A, Number_BP, Radial_P, BoundaryP, NewDeltaR, Number_RP, OldDeltaR, IMAXMAX)
    .
    .
    CALL INITIAL(G, H, IMAXMAX, MAXM, DeltaR)
    .
    .   This is the reentry point for a restart.
    .
333  CONTINUE
    .
    IMAX1 = IMAX - 1
    .
    .   To allow program restart, set the control break option. Once Ctrl C is

```

```

      pressed, the program will jump to the designated point, once detected.
      NEWTEST = .FALSE.
      OPTION BREAK(NEWTEST)

      Set the major program loop
100  NSTEP = NSTEP + 1
      Z = Z + DeltaZ
      IF (Z.GT.ZOUT(K)) THEN
        Z = ZOUT(K)
      ENDIF
      CALL NEXT(G,H)

      This simple four line section of code floats the transverse boundary.
      Calculate the amplitude four cells from the rigid boundary. If it has
      exceeded the threshold, expand if necessary. This works because the lowest
      index value corresponds to the lowest frequency.

      IF (IMAX.LT.IMAXMAX) THEN
        IF (Ampltu(G(IMAX4,1),H(IMAX4,1)).GT.Threshold) THEN
          IMAX = IMAX + 2
          IF (IMAX.GE.IMAXMAX) IMAX = IMAXMAX
          IMAX1 = IMAX - 1
          IMAX4 = IMAX - 4
        ENDIF
      ENDIF

      Now see whether the on-axis output is necessary by checking to see if the
      value corresponds to an element of zout(k).

      IF (Z.EQ.ZOUT(K)) THEN

        At each output point, write the on-axis amplitude and phase spectra.

        WRITE(11,1009) M , Z, (AMPLTU(G(0,N),H(0,N)),N = 0,M)
        WRITE(12,1009) M , Z, (PHASE(G(0,N),H(0,N)),N = 0,M)
        WRITE(*,500) Nstep, Z, k, M, Imax
500   FORMAT(' Nstep = ',I6,' Z = ',F10.6,' k = ',I3,' M = ',I3,' Imax = ',I4)
        K = K + 1
      ENDIF
1009  FORMAT(1P,I4,' ',500E16.4E4)
      IF(Z.EQ.ZU(L)) THEN

        If z is at the pont z(l) the increment the index in the zu(l) array.

        IF(L.LT.NDPOINTS) THEN
          L = L + 1
        ELSE
          L = NDPOINTS
        ENDIF

        This is the place to output the spectra to ampr and phaser.

        DO 2000 INEW = 0, IOUTMAX
          WRITE(13,1009) M, Z, (OldDeltaR * INEW), (AMPLTU(G(INEW,N),H(INEW,N)),N=0,M)
          WRITE(14,1009) M, Z, (OldDeltaR * INEW), (PHASE(G(INEW,N),H(INEW,N)),N=0,M)
2000  CONTINUE
        ENDIF
        IF (M.LT.MAXM) THEN
          IF (AMPLTU(G(0,M),H(0,M)).GT.Threshold) THEN
            M = M + 1
          ENDIF
        ENDIF
        IF(K.EQ.(TPOINTS+1)) GO TO 115

        If ^C has been pressed the go to 905.

        IF(NEWTEST) GOTO 905
        GOTO 100
115  CONTINUE

```

```

.
.   If finished, then reset restart to 0.
.
OPEN(5,FILE='RESTART')
RESTART = 0
WRITE(5,*) RESTART
CLOSE(5)
.
.   Now jump to 906.
.
GOTO 906
905 CONTINUE
.
.   If restarting, then write the relevant parameters.
.
OPEN(5,FILE='TEMP1.DAT')
WRITE(5,*) Case
WRITE(5,*) Threshold
WRITE(5,*) IoutMax
WRITE(5,*) Rgmax
WRITE(5,*) Rgain
WRITE(5,*) Rmax
WRITE(5,*) Alpha0
WRITE(5,*) Alpha
WRITE(5,*) AlphaD
WRITE(5,*) PO
WRITE(5,*) Ro0
WRITE(5,*) BoverA
WRITE(5,*) Bover2A
WRITE(5,*) D
WRITE(5,*) A
WRITE(5,*) DeltaR
WRITE(5,*) DeltaZ
WRITE(5,*) Zmin
WRITE(5,*) Zmax
WRITE(5,*) Z
WRITE(5,*) K
WRITE(5,*) L
WRITE(5,*) NSTEP
WRITE(5,*) IMAXMAX
WRITE(5,*) IMAXMIN
WRITE(5,*) IMAX
WRITE(5,*) IMAX4
WRITE(5,*) K1
WRITE(5,*) K2
WRITE(5,*) K3
WRITE(5,*) KN1
WRITE(5,*) KN2
WRITE(5,*) KN3
WRITE(5,*) KN4
WRITE(5,*) Npoints
WRITE(5,*) NDpoints
WRITE(5,*) Number BP
WRITE(5,*) Tpoints
DO 199 I = 1, NDpoints
  WRITE(5,*) ZU(I)
199 CONTINUE
DO 296 I = 0, Number BP - 1
  WRITE(5,*) BoundaryP(0,I),', ',BoundaryP(1,I)
296 CONTINUE
WRITE(5,*) MinM
WRITE(5,*) M
WRITE(5,*) MaxM
WRITE(5,*) CO
WRITE(5,*) Freq
WRITE(5,*) Omega
WRITE(5,*) Rayleigh
WRITE(5,*) Ld
WRITE(5,*) P1
WRITE(5,*) TwoP1

```

```

.
.   Now write the output array that was initially calculated.
.
DO 406 I = 1, Tpoints
  WRITE(5,*) ZOUT(I)
406 CONTINUE
  CLOSE(5)
.
.   Next write the arrays used for G and H in the calculation.
.
  CALL WRITETEMP(G, H, MAXM, IMAXMAX)
.
906 CONTINUE
  WRITE(*,*) 'PROGRAM EXECUTION COMPLETED'
.
.   Now close the output files
.
  CLOSE(11)
  CLOSE(12)
  CLOSE(13)
  CLOSE(14)
  STOP
  END

```

```
SUBROUTINE HEADER(N,Case,D,A,PO,DeltaR,Zmin,Zmax,IoutMax,Npoints,NDpoints,Number_BP,Tpoints,
  ZU,MinM,MaxM,Freq,BoundaryP)
```

```
  This subroutine writes a header on each output file
```

```
  DOUBLE PRECISION Zmin, Zmax, DeltaR, D, A, Freq, ZU(50), PO, BoundaryP(0:1,0:100)
  INTEGER CASE, I, Npoints, NDpoints, Tpoints, MinM, MaxM, N, IoutMax, Number_BP
  LOGICAL NEWTEST
  COMMON /ALL/ NEWTEST
```

```
  This is the collection of write statements
```

```
  WRITE(N,*) CASE
  WRITE(N,1000) D
  WRITE(N,1000) A
  WRITE(N,1000) PO
  WRITE(N,1000) DeltaR
  WRITE(N,1000) Freq
  WRITE(N,1000) Zmin
  WRITE(N,1000) Zmax
  WRITE(N,*) IoutMax
  WRITE(N,*) Npoints
  WRITE(N,*) NDpoints
  WRITE(N,*) Tpoints
  WRITE(N,*) MinM
  WRITE(N,*) MaxM
  DO 1002 I = 1,NDpoints
    WRITE(N,1000) ZU(I)
1002  CONTINUE
  DO 1003 I = 0, Number_BP - 1
    WRITE(N,*) BoundaryP(0,I), ' ', BoundaryP(1,I)
1003  CONTINUE
1000  FORMAT(1P,E15.6E3)
  RETURN
  END
```

```

SUBROUTINE READTEMP(G,H,MAXM,IMAX)
DOUBLE PRECISION G(0:4000,0:30), H(0:4000,0:30)
INTEGER MAXM,IMAX

```

• This subroutine reads files Temp2.dat through Temp5.dat.

```

•
•
OPEN(5,FILE='TEMP2.DAT')
DO 607 I=0,MAXM/2
  DO 608 J = 0,IMAX
    READ(5,*) G(J,I)
608   CONTINUE
607   CONTINUE
CLOSE(5)
OPEN(5,FILE='TEMP3.DAT')
DO 307 I=(MAXM/2)+1,MAXM
  DO 308 J = 0,IMAX
    READ(5,*) G(J,I)
308   CONTINUE
307   CONTINUE
CLOSE(5)
OPEN(5,FILE='TEMP4.DAT')
DO 617 I=0,MAXM/2
  DO 618 J = 0,IMAX
    READ(5,*) H(J,I)
618   CONTINUE
617   CONTINUE
CLOSE(5)
OPEN(5,FILE='TEMP5.DAT')
DO 317 I=(MAXM/2)+1,MAXM
  DO 318 J = 0,IMAX
    READ(5,*) H(J,I)
318   CONTINUE
317   CONTINUE
CLOSE(5)
RETURN
END

```



```

SUBROUTINE WRITETEMP(G,H,MAXM,IMAX)
DOUBLE PRECISION G(0:4000,0:30), H(0:4000,0:30)
INTEGER MAXM,IMAX

```

```

    This subroutine writes Temp2.dat through Temp5.dat

```

```

50  FORMAT(1P,4D30.15)
    OPEN(5,FILE='TEMP2.DAT')
    DO 100 I=0,MAXM/2
        DO 90 J = 0,IMAX
            WRITE(5,*) G(J,I)
90  CONTINUE
100 CONTINUE
    CLOSE(5)
    OPEN(5,FILE='TEMP3.DAT')
    DO 200 I=(MAXM/2)+1,MAXM
        DO 190 J = 0,IMAX
            WRITE(5,*) G(J,I)
190 CONTINUE
200 CONTINUE
    CLOSE(5)
    OPEN(5,FILE='TEMP4.DAT')
    DO 300 I=0,MAXM/2
        DO 290 J = 0,IMAX
            WRITE(5,*) H(J,I)
290 CONTINUE
300 CONTINUE
    CLOSE(5)
    OPEN(5,FILE='TEMP5.DAT')
    DO 400 I=(MAXM/2)+1,MAXM
        DO 390 J = 0,IMAX
            WRITE(5,*) H(J,I)
390 CONTINUE
400 CONTINUE
    CLOSE(5)
    RETURN
END

```

```

SUBROUTINE SET_BOUNDARY(A, Number_BP, Radial_P, BoundaryP, NewDeltaR, Number_RP,
                      OldDeltaR, Imax)
*
*   This subroutine calculates the initial normalized pressure distribution
*
*   Declared variables
*
*   A           = Transducer radius
*   Number_BP   = Number of experimental values
*   Number_RP   = Number of uniformly spaced radial points
*   BoundaryP   = Experimental point 2-D array
*   OldDeltaR   = Normalized step size
*   NewDeltaR   = Radial step size (meters)
*   Radius      = Radial location (meters)
*   Radial_P    = Uniformly spaced normalized pressure values
*   LocalIndex  = Array index for incrementing BoundaryP
*   I           = Loop index
*   Imax        = Maximum number of transverse terms
*   m           = Slope
*   b           = Y intercept
*
*   INTEGER Number_BP, LocalIndex, I, Number_RP, Imax
*   DOUBLE PRECISION Radial_P(0:4000), BoundaryP(0:1,0:100), NewDeltaR
*   DOUBLE PRECISION OldDeltaR, Radius, m, b, a
*
*   Set number of radial points. This value is passed to main program.
*
*   Number_RP = IDINT(1.0d0/OldDeltaR)
*   IF (DMOD(1.0d0,OldDeltaR).NE.0.0d0) Number_RP = Number_RP + 1
*
*   Given the number of radial points, set the pressure values. For a
*   uniform distribution set the pressure to 1 and go to the end.
*
*   IF (Number_BP.EQ.1) THEN
*     DO 100 I = 0, Number_RP
*       Radial_P(I) = 1.0d0
*     CONTINUE
*   DO 110 I = Number_RP + 1, Imax
*     Radial_P(I) = 0.0d0
*   CONTINUE
*   GOTO 500
* ENDIF
*
*   Now if we don't have a uniform distribution, construct a profile
*   based on the experimental points. Set the on axis point (0),
*   the local index, and radial step size (in meters).
*
*   Radial_P(0) = BoundaryP(1,0)
*   LocalIndex = 1
*   NewDeltaR = OldDeltaR * A
*
*   Now build the array
*
*   DO 200 I = 1, Number_RP
*     Radius = I * NewDeltaR
*
*     Check whether the radius is < BoundaryP(0,LocalIndex). If so,
*     interpolate to determine Radial_P(I).
*
*   210 CONTINUE
*     IF (Radius.LE.BoundaryP(0,LocalIndex)) THEN
*       m = (BoundaryP(1,LocalIndex) - BoundaryP(1,LocalIndex - 1))
*       b = m/(BoundaryP(0,LocalIndex) - BoundaryP(0,LocalIndex - 1))
*       m = BoundaryP(1,LocalIndex) - (m * BoundaryP(0,LocalIndex))
*       Radial_P(I) = (m * Radius) + b
*     ELSE
*
*     If not, increment the index and loop back.

```

```

      IF (LocalIndex .LT. (Number_BP - 1)) THEN
        LocalIndex = LocalIndex + 1
        GOTO 210
      ELSE
        Radial_P(I) = BoundaryP(1,LocalIndex)
      ENDIF
    ENDIF
200  CONTINUE
    DO 220 I = Number_RP + 1, Imax
      Radial_P(I) = 0.0d0
220  CONTINUE
500  CONTINUE
.
.    Now write the results to check the process.
.
    OPEN(5,File = 'TempFile.dat')
    Write(5,*) Number_RP
    Write(5,*) NewDeltaR
    Write(5,*) A
    Write(5,*) Number_BP
    Write(5,*) OldDeltaR
    Do 300 I = 0, Imax
      RADIUS = I * NewDeltaR
      Write(5,*) Radius,' ',Radial_P(I)
300  CONTINUE
    CLOSE(5)
.
.    Stop and return.
.
    RETURN
  END

```

```

SUBROUTINE INITIAL(G, H, IMAX, MAXM, DeltaR)

```

```

    This subroutine initializes the coefficients G and H at the transverse boundary.

```

```

DOUBLE PRECISION G(0:4000,0:30), H(0:4000,0:30), U, DeltaR
DOUBLE PRECISION INIAMP, INIPHS, A, D, Freq, CO, TwoPi, Pi
INTEGER MAXM, IMAX, I, N
LOGICAL NEWTEST
COMMON /ALL/ NEWTEST
COMMON /CONSTANTS/ A, D, Freq, CO, TwoPi, Pi

```

```

    Since only a single harmonic exists at the start, initialize G and H of (i,1).

```

```

DO 10 I=0,IMAX
  U = I * DeltaR
  IF (Radial_P(I).NE.0.000) THEN
    G(I,1) = Radial_P(I)*DCOS(INIPHS(U))
    H(I,1) = Radial_P(I)*DSIN(INIPHS(U))
  ELSE
    G(I,1) = 0.000
    H(I,1) = 0.000
  ENDIF
10 CONTINUE

```

```

    For safety's sake set all other terms to 0

```

```

DO 20 I = 0, IMAX
  DO 30 N = 2, MAXM
    G(I,N) = 0.000
    H(I,N) = 0.000
  30 CONTINUE
20 CONTINUE
RETURN
END

```

DOUBLE PRECISION FUNCTION INIPHS(U)

This procedure adjusts the phase of the input pressure front so that it appears to be coming from a curved surface.

DOUBLE PRECISION A, D, Rvalue, U, Freq, CO, TwoPi, Pi, K  
DOUBLE PRECISION DeltaR, DeltaZ, Rayleigh, Ld, AlphaD, Rmax  
LOGICAL NEWTEST  
COMMON /ALL/ NEWTEST  
COMMON /CONSTANTS/ A, D, Freq, CO, TwoPi, Pi  
COMMON /NEXTC/ DeltaR, DeltaZ, Rayleigh, Ld, AlphaD, Rmax

Convert from normalized radial coordinates to real coordinates.

$Rvalue = A * U * \sqrt{D / (4.000 * Rayleigh)}$

Calculate the wave number based on the input frequency

$K = TwoPi * Freq / CO$

Phase Factor

$INIPHS = K * (\sqrt{D^2 + Rvalue^2} - D)$

RETURN  
END

```

SUBROUTINE NEXT(G,H)
.
.   This subroutine calculates G and H for the next longitudinal distance step.
.
DOUBLE PRECISION G(0:4000,0:30), H(0:4000,0:30)
DOUBLE PRECISION GNEW(0:4000), HNEW(0:4000), NORM
DOUBLE PRECISION GFN(0:4000), HFN(0:4000), GOLD(0:4000), Rmax
DOUBLE PRECISION SUMG, SUMH, Eps, Rayleigh, A, D, Freq, CO, C3
DOUBLE PRECISION C1, C2, DeltaR, DeltaZ, Ld, AlphaD, TwoPi, Pi
INTEGER M, IMAX, LMAX, IMAX1
LOGICAL NEWTEST
COMMON /ALL/ NEWTEST
COMMON /CONSTANTS/ A, D, Freq, CO, TwoPi, Pi
COMMON /NEXTC/ DeltaR, DeltaZ, Rayleigh, Ld, AlphaD, Rmax
COMMON /INDEXES/ IMAX, M, IMAX1
.
.   Set the local convergence constants
.
Eps = 1.0d-5
LMAX = 20
.
.   These constants are calculated outside the loop to speed up the program.
.
DO 60 N=1, M
  C1 = DeltaZ * N * D / (2.000 * Ld)
  C2 = 1.000 / (1.000 + (DeltaZ * AlphaD * N * N))
  C3 = DeltaZ / (4.000 * N * DeltaR * DeltaR)
.
.   This loop calculates the non-linear term contribution.
.
  DO 10 I=0, IMAX1
    GOLD(I) = G(I,N)
    GFN(I) = GOLD(I) + C1 * SUMG(G,H,N,M,I)
    HNEW(I) = H(I,N)
    HFN(I) = HNEW(I) + C1 * SUMH(G,H,N,M,I)
10  CONTINUE
.
.   L is the convergence counter. If L exceeds 20, the program aborts.
.
  L = 1
.
.   Apply the seven point Lapacian
.
20  CALL CONVOL(GNEW,GFN,C2,C3,HNEW)
  CALL CONVOL(HNEW,HFN,C2,-C3,GNEW)
.
.   If the step to step error exceeds the convergence factor, continue to iterate.
.
  DO 50 I=0, IMAX1
    NORM = DABS(GNEW(I) - GOLD(I))
    IVAL = I
    IF (NORM.GT.EPS) GOTO 77
50  CONTINUE
.
.   If the step to step error is allowable, jump to the next step.
.
  GO TO 54
77  CONTINUE
  DO 59 I=0, IMAX1
    GOLD(I) = GNEW(I)
59  CONTINUE
.
.   If L ≥ 20, then terminate the program and write the diagnostics.
.
  IF (L.GT.LMAX) THEN
    WRITE(*,*) 'ITERATION FOR N = ',N,' FAILED. PROGRAM ABORT'
885  WRITE(*,885) NORM, Eps, L, IVAL
    FORMAT(1p,2d15.6,2I5)
    STOP
  ENDIF

```

```

.
.      Increment L and continue to iterate
.
      L = L+1
      GO TO 20
.
.      Set G and H to the new values
.
54      DO 53 I = 0,IMAX1
          G(I,N) = GNEW(I)
          H(I,N) = HNEW(I)
53      CONTINUE
55      CONTINUE
60      CONTINUE
      RETURN
      END

```

SUBROUTINE CONVOL(Z,X,C2,C3,Y)

This subroutine performs the seven point laplacian operator at each point in the Array Y.

DOUBLE PRECISION Z(0:4000), Y(0:4000), X(0:4000), C2, C3, K1, K2, K3  
 DOUBLE PRECISION KN1, KN2, KN3, KN4  
 INTEGER IMAX, M, IMAX1  
 LOGICAL NEWTEST  
 COMMON /ALL/ NEWTEST  
 COMMON /INDEXES/ IMAX, M, IMAX1  
 COMMON /KVALUE/ K1, K2, K3, KN1, KN2, KN3, KN4

Z = The output value which is G or H  
 X = The previous gridpoint value which is G or H  
 Y = The current grid value which is H or G  
 C2 =  $1.0D0 / (1.0D0 + (\text{DeltaZ} * \text{AlphaD} * N * N))$   
 C3 =  $D * \text{DeltaZ} / (4.0D0 * ZD * N * \text{DeltaR} * \text{DeltaR})$

Calculate the on-axis term, and the next two terms moving away from the axis

$Z(0) = C2 * (X(0) + C3 * (KN1 * (Y(3) + Y(3)) + KN2 * (Y(2) + Y(2)) + KN3 * (Y(1) + Y(1)) + KN4 * Y(0)))$   
 $Z(1) = C2 * (X(1) + C3 * (KN1 * (Y(4) + Y(2)) + KN2 * (Y(3) + Y(1)) + KN3 * (Y(2) + Y(0)) + KN4 * Y(1)))$   
 $Z(2) = C2 * (X(2) + C3 * (KN1 * (Y(5) + Y(1)) + KN2 * (Y(4) + Y(0)) + KN3 * (Y(3) + Y(1)) + KN4 * Y(2)))$

Next compute the terms up to the IMAX - 4

DO 10 I = 3, IMAX - 4  
 $Z(I) = C2 * (X(I) + C3 * (KN1 * (Y(I+3) + Y(I-3)) + KN2 * (Y(I+2) + Y(I-2)) + KN3 * (Y(I+1) + Y(I-1)) + KN4 * Y(I)))$

CONTINUE

End by calculating the terms at the upper boundary

$Z(IMAX-3) = C2 * (X(IMAX-3) + C3 * (K1 * (Y(IMAX-1) + Y(IMAX-5)) + K2 * (Y(IMAX-2) + Y(IMAX-4)) + K3 * Y(IMAX-3)))$   
 $Z(IMAX-2) = C2 * (X(IMAX-2) + C3 * (Y(IMAX-1) - 2.000 * Y(IMAX-2) + Y(IMAX-3)))$   
 $Z(IMAX-1) = C2 * (X(IMAX-1) + C3 * (Y(IMAX-2) - 2.000 * Y(IMAX-1)))$

Return to the main program

RETURN  
 END



```

.
.
.   This pair of functions is used to calculate linearized sum term at
.   each longitudinal step
.
.
DOUBLE PRECISION FUNCTION SUMG(G,H,N,M,I)
.
.   This function calculates the linearized contribution for G
.
DOUBLE PRECISION G(0:4000,0:30), H(0:4000,0:30), SUM
INTEGER K, N, M, I
LOGICAL NEWTEST
COMMON /ALL/ NEWTEST
SUM = 0.000
DO 10 K=1,(N-1)/2
    SUM = SUM+G(I,N-K)*G(I,K)-H(I,N-K)*H(I,K)
10 CONTINUE
    IF (MOD(N,2).EQ.0) THEN
        SUM = SUM + (0.5*(G(I,N/2)**2 - H(I,N/2)**2))
    ENDIF
    DO 20 K=M,(N+1),-1
        SUM = SUM-G(I,K-N)*G(I,K)-H(I,K-N)*H(I,K)
20 CONTINUE

SUMG = SUM

RETURN
END

.
.
.
DOUBLE PRECISION FUNCTION SUMH(G,H,N,M,I)
.
.   This function calculates the linearized contribution for H.
.
DOUBLE PRECISION G(0:4000,0:30), H(0:4000,0:30), SUM
INTEGER K, N, M, I
LOGICAL NEWTEST
COMMON /ALL/ NEWTEST
SUM = 0.000
DO 10 K=1,(N-1)
    SUM = SUM+G(I,N-K)*H(I,K)
10 CONTINUE
    DO 20 K=M,(N+1),-1
        SUM = SUM+G(I,K)*H(I,K-N)-H(I,K)*G(I,K-N)
20 CONTINUE

SUMH = SUM

RETURN
END

```

•

•

•

•

•

•

●

1

10  
20

# Phase of Lamb wave radiation from a plate immersed in a liquid

J.-F. Piet, G. Quentin, M. de Billy, Q.-G. Zhu† and W.G. Mayer†

Equipe d'Optique Ultrasonore, GPS, Université Paris 7, 75251 Paris Cedex 05, France

† Ultrasonics Research Laboratory, Physics Department Georgetown University, Washington, DC 20057, USA

Received 28 February 1992

A stroboscopic Schlieren image of ultrasonic radiation from a plate immersed in water is presented and is compared with the calculated radiation pattern for the plate in which a leaky Lamb mode has been generated. The phase relationship of the radiation lobes created at the top, bottom, and narrow end surfaces of the plate are discussed.

**Keywords:** leaky Lamb modes; Schlieren imaging; radiation pattern phase

It was recently shown<sup>1,2</sup> that Lamb waves in a solid plate immersed in water radiate some of their energy from the end of the plate. This radiation from the end of the plate consists of an odd number of lobes when the plate carries a symmetric Lamb mode and an even number of lobes when the mode is antisymmetric. The previously published Schlieren images produced by continuous waves and theoretical calculations of the relative intensity distribution between the lobes<sup>2</sup>, as well as hydrophone measurements<sup>1</sup> do not indicate the respective phase of the radiation. Moreover, the use of continuous waves incident from the water onto the plate to generate a given leaky Lamb mode also produces specular and non-specular reflections, first observed by Schoch<sup>3</sup>, and later explained and described by Neubauer<sup>4</sup>, Bertoni and Tamir<sup>5</sup>, and others<sup>6,7</sup>. When these reflections of the incident continuous wave occur near the end of the plate, they may interfere with other possible reradiations from the end of the plate. The Schlieren images published by Zhu *et al.*<sup>1</sup> clearly show reflections from, and transmissions through, the plate which are caused by such interferences. They are not specular or non-specular reflections since the radiation is not taking place at the expected Lamb angle.

However, the numerical approach used to find the intensity distribution of the radiation at the end of the plate<sup>2</sup> does contain information from which relative phases of the waves in the lobes can be determined. Furthermore, the numerical method can be used to describe radiation from the top and the bottom of the plate, near its end, which does not include specular and non-specular reflections. The latter are simply a consequence of a particular technique of exciting Lamb modes and, thus, may be considered not to be a part of the radiation from a Lamb mode *per se*.

This paper is concerned with the phase and the amplitude distribution of the radiation occurring at the

end of the plate as well as from the top and the bottom near the plate's end. The interference by incident or reflected waves has been eliminated in both the mathematical model and the experimental arrangement described.

## Calculational approach

The basis for the calculations are the finite different methods discussed by Bond<sup>8</sup> and Harker<sup>9</sup>, adopted for the present case of energy transfer from the particle displacement at the end surfaces of an aluminium plate to the surrounding water. This particle displacement can be calculated for a plate vibrating in a Lamb mode which is excited by a longitudinal ultrasonic wave in water, incident at the appropriate Lamb angle.

Assuming that the long dimension of the plate is the  $x$ -direction, the thickness of the plate is in the  $z$ -direction and the Lamb wave propagates in the  $x$ -direction, then the wave motion in the homogeneous solid plate can be expressed as

$$(\lambda + \mu)\nabla\nabla \cdot u + \mu\nabla^2 u = \rho \frac{\partial^2 u}{\partial t^2} \quad (1)$$

Here  $\lambda$  and  $\mu$  are the Lamé constants,  $\rho$  is the density of the plate material, and  $u$  is the displacement vector which has an  $x$  and  $y$  component and is time dependent. The  $y$ -direction can be omitted assuming the plate to be wide enough to eliminate any  $y$ -dependence. With the velocities of the longitudinal and shear waves given, respectively by

$$p^2 = (\lambda + \mu)/\rho \quad (2)$$

$$s^2 = \mu/\rho \quad (3)$$

The general equations for the particle displacements in

the  $x$  and  $z$  directions,  $u$  and  $v$ , respectively, are then

$$u_{tt} = p^2 u_{xx} + (p^2 - s^2) v_{xz} + s^2 u_{zz}, \quad (4)$$

$$v_{tt} = p^2 v_{zz} + (p^2 - s^2) u_{xz} + s^2 v_{xx}, \quad (5)$$

the subscripts indicate derivatives.

The Lamb wave to be examined is produced by allowing an ultrasonic beam of frequency  $f$  (with  $f$  between 2 and 10 MHz) to be incident at the appropriate angle from the water on to the plate so that the desired Lamb mode is set up in the plate. Other parameters needed for a numerical analysis are the beam profile, beam width, plate thickness  $d$ , and distance from the point of beam incidence on the plate to the end of the plate. In the present case the plate was 0.9 mm thick, and the distance beam to the end of plate could be varied. The beam profile was assumed to be Gaussian.

Equations (4) and (5) can then be solved by the FDM with incremental steps of  $x$  of about  $0.1\lambda$  and the increments of  $t$  are selected so that

$$\Delta t \leq \Delta x (p^2 + s^2)^{-1/2} \quad (6)$$

If the size of the time and space increments are selected so that Equation (6) is satisfied, the accuracy and stability of the calculation will be assured<sup>10</sup>.

### Numerical calculations

The above method was used to calculate the radiation pattern at the end of the plate vibrating in the  $A_1$ -Lamb mode. The frequency of the continuous wave was assumed to be 3.29 MHz and the plate thickness 0.9 mm, resulting in an  $fd$ -value of 2.96 MHz mm. The  $A_1$ -Lamb mode will be excited for these parameters if the angle of incidence in water is  $13.6^\circ$ .

This set of parameters is used as the input. The output is an array of calculated sound-intensity values for 43 points along the  $x$ -direction and 34 points in the  $z$ -direction. Since calculations are made at incremental distances of 0.1 mm in these two directions, the mapped area is 4.2 mm by 3.3 mm, which means that there are 1462 calculated intensity values in the mapped area.

Gridding software is used to establish as many additional intensity values as desired, located between the calculated data points, and to create contour lines connecting identical intensity values. Software was also used to find the maximum value of the intensity in the radiated energy in the water in the mapped area which, in the case discussed here, was approximately 0.033 of the maximum value of the intensity of the Gaussian beam incident at the water-solid interface of the plate.

Figure 1 shows the intensity distribution in the mapped area. The contour lines are 1 dB apart, starting with those lines connecting the maximum intensity points in the lobes and ending with those lines connecting intensity points -10 dB below that value. No lines are drawn in areas where the intensity is more than 10 dB below the maximum. All points with intensity values above the maximum in water are connected with one line, regardless of how much higher the intensity value is at those points, compared with the maximum intensity in water. Clearly this results in a dark area, representing the plate where the intensity is generally very much higher than in the reradiation pattern in the lobes in the water.

The intensity representation in Figure 1 depicts the situation at a given time increment, in this case 34 periods




Figure 1 Calculated intensity distribution of an ultrasonic field in water created by reradiation of an  $A_1$ -Lamb mode in an aluminium plate. Plate thickness  $d = 0.9$  mm and parameter  $fd = 2.96$  MHz mm



Figure 2 Stroboscopic Schlieren image of radiation lobes for an aluminium plate in water. Parameters are the same as used for Figure 1

after the start of the generation of the Lamb wave in the plate. Therefore, the reradiation pattern around the end of the plate is well established, the high-intensity areas in the water represent the location of the positive and negative maximum pressure amplitudes in the lobes, i.e. the  $\frac{1}{2}\lambda$  locations of the 3.29 MHz wave in the water. Based on this particular appearance of the low lobes radiating from the end of the plate one cannot determine whether the water in the lobes are in phase or  $180^\circ$  out of phase as they leave the plate. This is also the case for a Schlieren image of the ultrasonic field at the end of the plate, as shown in Figure 2.

This image was obtained by creating a Schlieren image of the ultrasonic field where the light source consisted of a small HeNe laser whose output was modulated by a Bragg cell. The time delay between the generation of the leaky Lamb mode and the stroboscopic illumination of the resulting radiation field could be adjusted. The image presented here shows the radiation field created by an incident 'tone burst' consisting of four cycles, with the

frequency, mode, and plate dimensions being the same as used for the calculations (Figure 1). Also visible in Figure 2 are portions of the transmitted and reflected tone burst, consisting of long, straight wave fronts. Their interference with reradiation lobes, can be held to a minimum when the tone burst is short.

A comparison of Figures 1 and 2 shows that it is possible to calculate and thus predict radiation patterns and lobe structures of plates immersed in a liquid and vibrating in a given Lamb mode. However, the calculation can also predict the relative phase of the waves in the radiation lobes.

Figure 3 shows the amplitude distribution in the two lobes generated at the narrow end of the plate with only the positive  $x$ -direction particle displacements considered. The negative-going half cycles of the waves have been suppressed in the graph and thus it becomes evident that the waves in the two lobes are  $180^\circ$  out of phase. The contour lines within every section of the waves indicate the levels of amplitude in ten equal steps from the maximum to zero amplitude with the lowest contour corresponding to the location of the zero-amplitudes of the waves. The wavefronts show an increasingly noticeable curvature with the circular pattern being centred at the centre of the narrow end of the plate.

Radiation lobes from the top and bottom surfaces of the plate are visible in Figures 1 and 2. The points where the two lobes at the top and the bottom of the plate originate are separated by one half-wavelength of the leaky  $A_1$ -Lamb mode. Results obtained with the FDM indicate that these lobes have intensity variations along




Figure 3 Calculated wavefront pattern for radiation from the narrow plate end considering only positive displacement amplitudes




Figure 4 Calculated wavefront pattern for radiation from the top and bottom surfaces, considering only positive displacement amplitudes

their propagation directions which are cyclic. The lobes originating at the plate top and bottom surfaces, as shown in Figure 1, have high intensities at the point of origin for the lobes close to the narrow end of the plate while the lobes originating farther away from the end of the plate have a low intensity at the point of origin. However, if the time increment between generation and radiation of the Lamb mode is changed the resulting high intensity areas in the lobes move along the propagation direction.

The phase relationship between the wavefronts within the lobes originating on the top and bottom surfaces as well as the narrow end of the plate can be seen by comparing the intensity distribution in the ultrasonic field (Figure 1) with the amplitude distribution (Figures 3 and 4) which shows that the waves in adjacent lobes are  $180^\circ$  out of phase. Figures 3 and 4 reveal the phase information which is not available from an observation of the experimental results shown in Figure 2, or from the results of intensity calculations shown in Figure 1.

#### Acknowledgement

One of the authors (WGM) gratefully acknowledges financial support by the Physics Division, Office of Naval Research, US Navy.

## References

- 1 Zhu, Q.-G., Ruf, H.J. and Mayer, W.G. *Ultrasonics* (1991) 29 459
- 2 Paraige, P., Luppé, F. and Ripoche, J. *J Acoust Soc Am* (1991) 89, pt. 2, 1992
- 3 Schoch, A. *Acustica* (1952) 2, 18
- 4 Neubauer, W.G. *J Appl Phys* (1973) 44, 48
- 5 Bertoni, H.L. and Tamir, T. *Appl Phys* (1973) 2, 157
- 6 Pitts, L.E., Plooa, T.J. and Mayer, W.G. *IEEE Trans Son Ultrason* (1977) 24, 101
- 7 Ngoc, T.D.K. and Mayer, W.G. *J Acoust Soc Am* (1980) 67, 1149
- 8 Bond, L.J. *Ultrasonics* (1979) 17, 71
- 9 Harker, A.H. *J NDT* (1984) 4, 89
- 10 Alterman, Z.S. and Loewenthal, D. *Geophys Roy Astron Soc* (1970) 20, 101

# On the crossing points of Lamb wave velocity dispersion curves

Qigao Zhu and Walter G. Mayer

Ultrasonics Research Laboratory, Physics Department, Georgetown University, Washington, DC 20057

(Received 22 September 1992; accepted for publication 9 December 1992)

Standard dispersion curves relating the phase velocity of Lamb waves to the frequency-plate thickness parameter  $fd$  indicate that in some cases symmetrical and antisymmetrical mode velocity curves cross each other. Viktorov's equations are used to show that the crossing points are points where the dispersion curves are discontinuous so that no distinct Lamb mode exists for these particular velocity- $fd$  combinations. Procedures are given to predict how many such points exist and where they are located in a given range of  $fd$ .

PACS numbers: 43.35.Pt

## INTRODUCTION

Lamb modes are either symmetric or antisymmetric and their velocity of propagation depends on the frequency of the mode  $f$  and the thickness  $d$  of the solid plate supporting the mode as well as on the bulk wave velocities of the material. If one plots the phase velocity of the various symmetrical Lamb modes as a function of the product  $f \cdot d$  one obtains a family of curves none of which crosses another. The same is true for a plot of the antisymmetrical modes. However, if the two families of curves are plotted together there are some instances where symmetric and antisymmetric curves seem to cross, as is evident from a representative example shown in Fig. 1 which applies to aluminum plates.

This implies that the plate supports a symmetrical and an antisymmetrical mode at the same time, both modes propagating with the same phase velocity, if the plate thickness  $d$  and the mode frequency  $f$  is such that the product  $fd$  is the  $fd$  value of the "crossing point." The resulting particle displacement within the plate could then be a superposition of two different modes with the vibrational mode of the plate not being defined as a Lamb mode. If one were to assume that no pure Lamb mode exists at crossing points, the defining equations given by Viktorov<sup>1</sup> should not be satisfied for those particular sets of parameters. Viktorov's basic wave equations (I.2) lead to a  $4 \times 4$  determinant, which in turn lead to two characteristic equations, determining the eigenvalues of the wave numbers of the modes, given by Viktorov as Eqs. (II.4) and (II.5). One can now use these equations to calculate the value of the defining determinant for the values of  $f \cdot d$  and the phase velocity of the Lamb modes at the crossing point.

A computation was performed, using double precision, of the value of the determinant for the crossing point located near the value of  $f \cdot d = 8.5$  MHz mm and the phase velocity of around 6.9396 km/s, shown in Fig. 1. These calculations for the value of the determinant were performed by changing the values of  $f \cdot d$  in increments of  $10^{-8}$  MHz mm and  $c$  in increments of 0.1 mm/s. The result is that for the velocity range  $c = 6.9396744$  to  $c = 6.9396764$  km/s and the  $f \cdot d$  range from 8.45435146 to 8.45435157 MHz mm the determinant is nonzero. This result would indicate that a Lamb mode does not exist at

points where the velocity dispersion curves for the symmetrical and the antisymmetrical modes cross.

The calculations leading to this result are rather involved and would be very taxing if all the crossing points had to be found with no prior knowledge of the approximate location of these points. Fortunately, a much shorter method is available to determine the location of those points on the families of velocity dispersion curves where no solution to the defining Lamb equations exist. This method will be discussed below.

## I. THEORETICAL CONSIDERATIONS

Noting that the phase velocities of Lamb modes at critical crossing points are greater than the bulk longitudinal wave velocity, one can use the defining Lamb mode equations for the symmetrical and antisymmetrical modes, respectively, as given by Viktorov<sup>1</sup>

$$\tan \alpha / \tan \beta + B = 0, \quad (1)$$

$$\tan \beta / \tan \alpha + B = 0, \quad (2)$$

where

$$\alpha = (\pi p f d) / c_p, \quad (3)$$

$$\beta = (\pi q f d) / c_p, \quad (4)$$

$$p = \sqrt{1 - (c_l/c)^2}, \quad (5)$$

$$q = \sqrt{(c_l/c)^2 - (c_t/c)^2}, \quad (6)$$

$$B = \frac{4(c_l/c)^2 p q}{[2(c_l/c)^2 - 1]} > 0, \quad (7)$$

with  $c$ , the shear wave velocity of the bulk solid,  $c_l$  the longitudinal wave velocity, and  $c_t$  the phase velocity of a Lamb mode defined by Eqs. (1) and (2).

As written, Eqs. (1) and (2) apply as long as  $c > c_l$ . This is the region of interest for the present purpose. One can write general expressions for the defining equations

$$S(c, fd) = \tan \alpha / \tan \beta + B, \quad (8)$$

$$A(c, fd) = \tan \beta / \tan \alpha + B. \quad (9)$$




FIG. 1. Section of Lamb mode velocity dispersion curves for aluminum showing the phase velocity  $c$  and thickness-frequency parameter  $fd$  for the first four mode crossing points.

Solutions of Viktorov's equations are determined by the roots of  $S(c, fd)$  and  $A(c, fd)$ , i.e., the values of  $c$  and an appropriate  $fd$  are defined for an  $S$  mode and an  $A$  mode when  $S(c, fd)$  or  $A(c, fd)$ , respectively, are zero.

## II. CRITICAL POINTS OF VIKTOROV'S EQUATIONS

The variables  $\alpha$  and  $\beta$  are the functions of the parameters  $c$  and  $fd$ . Thus, for any given phase velocity  $c$ ,  $\tan \alpha$  and  $\tan \beta$  are periodic functions of  $fd$ , where the periodicities are  $c/p$  and  $c/q$ , respectively. The arguments of both tangent functions are zero for  $fd=0$ , regardless of the value of  $c$ . With increasing values of  $fd$ , the values of  $S(c, fd)$  and  $A(c, fd)$  usually remain nonzero; however, in order to satisfy Viktorov's equations they must be zero which occurs only when either  $\tan \alpha / \tan \beta = -B$  or  $\tan \beta / \tan \alpha = -B$  according to Eqs. (8) and (9).

These conditions on Eqs. (8) and (9) must be satisfied simultaneously at mode crossing points in the  $c$ - $fd$  plane if an  $A$  mode as well as an  $S$  mode are to exist at such points. Investigating the behavior of the two tangent functions one finds that two types of critical points may exist where there are no solutions to Viktorov's equations. As will be shown below, these critical points in the  $c$ - $fd$  plane are identical to the mode crossing points; one of these points was identified in the introductory discussion of the determinant solution.

Type I critical points exist when the respective values of  $\tan \alpha$  and  $\tan \beta$  both reach infinity at the same value of  $fd$  which occurs when

$$\alpha = (\pi p fd) / c_i = (m + \frac{1}{2})\pi, \quad (10)$$

$$\beta = (\pi q fd) / c_i = (n + \frac{1}{2})\pi, \quad (11)$$

for certain values of the integers  $m$  and  $n$  and for certain values of  $p$  and  $q$  which in turn are functions of the phase velocity.

Type II critical points exist when  $\tan \alpha$  and  $\tan \beta$  reach zero at the same value of  $fd$  that requires that the arguments are

$$\alpha = (\pi p fd) / c_i = m\pi, \quad (12)$$

$$\beta = (\pi q fd) / c_i = n\pi. \quad (13)$$

The procedure to determine at what values of  $c$ ,  $fd$ , and  $m$  and  $n$  type I and type II critical points occur for a set of Lamb mode velocity dispersion curves consists of combining Eqs. (10) and (11) for the type I points, and Eqs. (12) and (13) for type II critical points.

As an example consider the procedure for type I critical point evaluation for an aluminum plate where the longitudinal and shear bulk wave velocities are, respectively, 6.42 and 3.04 km/s. These are the same values that were used in the determinant calculation mentioned in the Introduction above.

Treating  $m$  and  $n$  as integers whose magnitude is not specifically assigned, Eqs. (10) and (11) are two equations with two unknowns, i.e., a critical value of  $fd$  and a critical value of  $c$  in  $p$  and  $q$ , respectively. Not specifying for the moment the value of  $fd$  but knowing that  $fd$  will have to be the same in  $\alpha$  and  $\beta$  where a critical point is located, one can substitute the expression for  $fd$  from Eq. (10) into Eq. (11) and solve for  $c$  in terms of  $m$  and  $n$ . This yields the following expression for the critical phase velocity,  $c_c$ :

$$c_c = \sqrt{\frac{(m + \frac{1}{2})^2 - (n + \frac{1}{2})^2}{(m + \frac{1}{2})^2 (c_r/c_i)^2 - (n + \frac{1}{2})^2}} c_r \quad (14)$$

For the critical phase velocity to be real, nonzero, and greater than the longitudinal wave velocity, the conditions for  $m$  and  $n$  are

$$m \neq n, \quad m > n, \quad (m + \frac{1}{2}) / (n + \frac{1}{2}) > c_r/c_i = 2.12 \text{ for Al.}$$

For these conditions and the condition that  $\tan \alpha$  and  $\tan \beta$  go to infinity at the same  $fd$ , one finds only three  $(m, n)$  combinations, (1,0), (2,0), and (3,0) for the range of the parameter  $fd$  given by  $0 < fd < 12$ .

Substituting these three sets of values for  $(m, n)$  into Eq. (14) yields three critical phase velocities. The three corresponding critical  $fd$  values are found by substituting the three sets of  $c_c$  and  $(m, n)$  into either Eq. (10) or Eq. (11) to solve for the value of  $fd$ . The three critical points for aluminum are thus found at

$$c = 8.5221 \text{ km/s}, \quad fd = 4.88 \text{ MHz mm}, \quad (m, n) = (1, 0),$$

$$c = 6.9396 \text{ km/s}, \quad fd = 8.45 \text{ MHz mm}, \quad (m, n) = (2, 0),$$

$$c = 6.6647 \text{ km/s}, \quad fd = 11.96 \text{ MHz mm}, \quad (m, n) = (3, 0).$$

Type II critical points are determined in a similar fashion by using Eqs. (12) and (13). Following essentially the same procedure as outlined above, one finds the possible critical velocities to be given by

$$c_c = \sqrt{\frac{m^2 - n^2}{m^2 (c_r/c_i)^2 - n^2}} c_r \quad (15)$$

Making the appropriate substitutions one finds only one  $(m, n)$  set in the range  $0 < fd < 12$ . This single type II critical point has the values

$$c = 8.5221 \text{ km/s}, \quad fd = 9.76 \text{ MHz mm}, \quad (m, n) = (3, 1).$$

Comparing these results with the mode velocity curves of Fig. 1 shows that the four calculated critical points are the only crossover points of  $A$  and  $S$  modes in the range



$0 < fd < 12$ . Inasmuch as the parameters of the critical points do not satisfy Viktorov's defining equations, the crossover points are not valid solutions either and neither an antisymmetrical nor a symmetrical mode exists at these points.

### III. CONCLUSION

The Lamb mode velocity dispersion curves generally exhibit a number of points where an  $A$  mode and an  $S$  mode cross which seems to imply that for that particular set of parameters a solid plate should be able to support a symmetrical as well as an antisymmetrical mode. Examining the simplest form of Viktorov's equation shows that the parameters defining these crossing points do not constitute

a solution to the equations, thus these unique points are not parts of either the symmetrical or antisymmetrical velocity dispersion curves. The relatively simple procedure described here can be used to find the number of crossing points of Lamb mode velocity dispersion curves as well as their velocity and  $fd$  parameters of these points.

### ACKNOWLEDGMENT

This work was supported by the Office of Naval Research, U.S. Navy.

<sup>1</sup>I. A. Viktorov, *Rayleigh and Lamb Waves: Physical Theory and Applications* (Plenum, New York, 1967).